

TECHNICAL MANUAL

**OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT,
AND GENERAL SUPPORT MAINTENANCE MANUAL
INCLUDING REPAIR PARTS AND SPECIAL TOOLS LIST
(INCLUDING DEPOT REPAIR PARTS AND SPECIAL TOOLS LIST)**

**GENERATOR
SWEEP SIGNAL
AN/USM-203A**

**This copy is a reprint which includes current
pages from Change 1.**

TECHNICAL MANUAL }
 No. 11-6625-2575-14 }

HEADQUARTERS
 DEPARTMENT OF THE ARMY
 WASHINGTON, DC, 23 November 1973

**OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT,
 AND GENERAL SUPPORT MAINTENANCE
 MANUAL
 GENERATOR, SWEEP SIGNAL
 AN/USM-203A
 (NSN 625-00-935-0145)**

REPORTING OF ERRORS


You can improve this manual by recommending improvements using DA Form 2028 located in the back of the manual. Simply tear out the self addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Form 2028-2 in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Communications and Electronics Readiness Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, NJ 07703.

	Paragraph	Page
General		
CHAPTER 1. INTRODUCTION		
Section I.	1-1	1-1
II. Description and data	1-8	1-1
CHAPTER 2. SERVICE UPON RECEIPT AND INSTALLATION	2-1	2-1
3. OPERATING INSTRUCTIONS		
Section I. Controls and instruments	3-1	3-1
II. Operation under usual conditions	3-3	3-3
III. Operation under unusual conditions	3-5	3-4
CHAPTER 4. OPERATOR/CREW MAINTENANCE INSTRUCTIONS	4-1	4-1
5. ORGANIZATIONAL MAINTENANCE		
Section I. General requirements	5-1	5-1
II. Externally serviceable details	5-3	5-1
CHAPTER 6. FUNCTIONING OF EQUIPMENT	6-1	6-1
7. DIRECT SUPPORT MAINTENANCE		
Section I. General	7-1	7-1
II. Troubleshooting	7-3	7-2
III. Repairs	7-6	7-9
IV. Test procedures	7-8	7-9
V. Alignment and adjustment procedures	7-12	7-13
CHAPTER 8. GENERAL SUPPORT MAINTENANCE		
Section I. General	8-1	8-1
II. Troubleshooting and repair	8-3	8-1
III. Replacement of rf assemblies	8-8	8-5
IV. Test procedures	8-14	8-7
V. Alignment and adjustment procedures	8-17	8-8
APPENDIX A. REFERENCES		A-1
APPENDIX B. DELETED		
APPENDIX C. MAINTENANCE ALLOCATION		
Section I. Introduction		C-1
II. MAINTENANCE ALLOCATION CHART		C 3
Table I. TOOL AND TEST EQUIPMENT REQUIREMENTS		C-4
Index		Index-1

LIST OF ILLUSTRATIONS

<i>Number</i>	<i>Title</i>	<i>Page</i>
1-1	Front view of AN/USM-203A	1-0
1-2	Typical Setup Using AN/USM-203A	1-2
2-1	AN/USM-203A Packaging	2-1
3-1	AN/USM-203A Front Panel Features	3-1
3-2	AN/USM-203A Rear Panel Features	3-2
7-1	AN/USM-203A With Enclosure Panels Removed	7-2
7-2	Typical Display at Q102 Collector	7-4
7-3	Typical Display at Q105 Emitter.	7-4
7-4	Typical Display at Q106 Collector	7-4
7-5	Typical Display at Q107 Collector	7-4
7-6	Typical Display at J301-4	7-4
7-7	Typical Display at J302-4 and J303-4	7-4
7-8	Typical Display at Q305 Collector	7-5
7-9	Main Printed Circuit Board Assembly	7-7
7-10	Plug-in Marker/Printed Circuit Board Assembly	7-8
7-11	Plug-in Marker Switch Bank	7-9
7-12	Test Setup for Typical Test Display	7-11
7-13	High Bank Test Display	7-11
7-14	Low Band Test Display	7-12
7-15	Connection of Plug-in Markers	7-16
7-16	115 Volt/230 Volt Input Power Option	7-16
8-1.	Rf Detector Assembly	8-2
8-2.	Monitor/Mixer Assembly A4A5	8-4
8-3.	Fixed Oscillator/Mixer/Filter Assembly A4A3	8-5
8-4.	AN/USM-203A, Block Diagram.	8-9
8-5.	Video Amplifier Assembly	8-10
8-6.	Video Amplifier Circuit Board A4A2, Resistor Location	8-10
8-7.	Video Amplifier Circuit Board A4A2, Capacitor Location	8-11
8-8.	Variable Oscillator Base-Plate Component Layout	8-11
8-9.	Rf Band Switch Assembly	8-12
8-10.	Rotary Attenuator Assembly	8-13
8-11.	Harmonic Marker Assembly	8-14
8-12.	1.0-MHz Harmonic Marker Printed Circuit Assembly	8-14
8-13.	10.0-MHz Harmonic Marker Printed Circuit Assembly	8-14
8-14.	50-MHz Harmonic Marker Printed Circuit Assembly	8-15
FO-1.	Resistor and Capacitor Color Codes	Fold-in
FO-2.	AN/USM-203A, Wiring Diagram	Fold-in
FO-3.	AN/USM-203A, Schematic Diagram	Fold-in



EL 6625-2575-14-TM-1

Figure 1-1. Front view of AN/USM-203A.

CHAPTER 1 INTRODUCTION

Section I. GENERAL

1-1. Scope

This manual describes Sweep Signal Generator AN/USM-203A. It covers the purpose, use, instructions for installation and operation, and the technical characteristics of the AN/USM-203A. The following maintenance categories are covered: operator/crew (C), organizational (O), direct support (F), and general support (H).

1-2. Indexes of Publications

a. *DA Pam 310-4.* Refer to DA Pam 310-4 to determine whether there are new editions, changes, or additional publications pertaining to the equipment.

b. *DA Pam 310-7.* Refer to DA Pam 310-7 to determine whether there are modification work orders (MWO's) pertaining to the equipment.

1-3. Forms and Records

a. *Reports of Maintenance and Unsatisfactory Equipment.* Maintenance forms, records, and reports which are to be used by maintenance personnel at all maintenance levels are listed in and prescribed by TM 38-750.

b. *Report of Packaging and Handling Deficiencies.* Fill out and forward DD Form 6 (Packaging Improvement Report) as prescribed in AR 700-58/NAVSUPINST 4030.29/AFR 71-13/MCO P4030.29A, and DSAR 4145.8.

c. *Discrepancy in Shipment Report (DISREP) (SF 361).* Fill out and forward Discrepancy in

Shipment Report (DISREP) (SF 361) as prescribed in AR 55-38/NAVSUPINST 4610.33 B/AFR 75-18/MCO P4610.19C and DLAR 4500.15.

1-4. Reporting Equipment Improvement Recommendations (EIR)

EIR's will be prepared using Standard Form 368, Quality Deficiency Report. Instructions for preparing EIR's are provided in TM 38-750, The Army Maintenance Management System. EIR's should be mailed direct to Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, NJ 07703. A reply will be furnished direct to you.

1-5. Administrative Storage

There is no special procedures for preparing this equipment for limited storage. Place all ancillary items in a bag and tie or tape the bag to the equipment. Place equipment in limited storage, ie, organizational storage room. Protect equipment from dust, humidity, and extreme temperature changes.

1-4. Destruction of Army Material

Demolition and destruction of electronic equipment will be under the direction of the commander and in accordance with TM 750-244-2.

1-7. Deleted

Section II. DESCRIPTION AND DATA

1-8. Purpose and Use

The AN/USM-203A is a source of rf energy which provides both fixed frequency and sweep fre-

quency signals. Frequency, sweep frequency, and sweep rate are adjustable from front panel controls. The frequency range covered is 500 kHz