

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

---

ORGANIZATIONAL, DIRECT SUPPORT, GENERAL SUPPORT  
AND DEPOT MAINTENANCE MANUAL  
INCLUDING REPAIR PARTS AND SPECIAL TOOLS LISTS

OSCILLOSCOPES  
AN/USM-140B,  
AN/USM-140C,  
AN/USM-141A,  
AND AN/USM-141B

This copy is a reprint which includes current  
pages from Changes 1 thru 3.

---

HEADQUARTERS, DEPARTMENT OF THE ARMY  
MAY 1966

TABLE OF CONTENTS

Paragraph	Page	Paragraph	Page
<b>SECTION A-INTRODUCTION</b>			
A-1. Indexes of publications .....	1-0.1	3-3. Description of Controls and Connectors ..	3-1
A-2. Forms and records.....	1-0.1	3-4. Operating Precautions .....	3-1
A-3. Reporting of errors.....	1-0.1	3-5. Operating Procedures .....	3-1
<b>SECTION 1-GENERAL DESCRIPTION</b>			
1-1. Scope .....	1-1	3-6. Procedure for Turning On Oscilloscope; Compensating Test Prods and Making Initial Electrical Inspection .....	3-1
1-1.1. Items comprising an operable equip- ment .....	1-1	3-7. Selecting and Synchronizing the Sweep and Its Magnification .....	3-1
1-2. General Description .....	1-1	3-8. Horizontal Deflection by External Signals .....	3-5
1-3. Description of Units .....	1-1	3-9. Dual Trace Operation .....	3-5
a. Oscilloscope OS-121B/USM-140 .....	1-1	3-10. Differential Operation .....	3-7
b. Oscilloscope Subassembly, Vertical Channel, Dual- Trace Preamplifier .....	1-1	3-11. Signal-Sweep Operation .....	3-7
c. Oscilloscope Subassembly, Horizontal Channel, Auxiliary Plug-in Unit .....	1-1	3-12. Operation with Intensity Modulation .....	3-8
1-4. Reference Data .....	1-1	3-13. Operation with Direct Connection to CRT for Vertical Deflection .....	3-8
a. Each Vertical Channel .....	1-1	3-14. Summary of Operating Procedures .....	3-8
b. Differential Input .....	1-2	3-15. Turn-Off Procedure .....	3-8
c. Sweep and Synchronization .....	1-2	3-16. Operator's Maintenance .....	3-8
d. Horizontal Amplifier .....	1-2	3-17. Operating Checks and Adjustment .....	3-8
e. Calibrator .....	1-2	a. Vertical Sensitivity Check .....	3-8
f. Cathode Ray Tube .....	1-2	b. Balance Check .....	3-9
g. Power Requirements .....	1-2	c. Horizontal Sensitivity Check .....	3-9
h. Dimensions .....	1-2	3-18. Preventive Maintenance .....	3-9
1-5. Equipment Supplied .....	1-2	3-19. Emergency Maintenance .....	3-9
1-6. Equipment and Publications Required But Not Supplied .....	1-2	a. Thermal Switch .....	3-9
1-7. Auxiliary Accessory Equipment.....	1-6	b. Fuse Replacement .....	3-9
1-8. Equipment Similarities.....	1-7, 1-8	c. Emergency Replacement of Tubes and Semiconductors .....	3-9
1-9. Factory or Field Changes.....	1-7, 1-8	<b>SECTION 4-TROUBLE SHOOTING</b>	
1-10. Preparation for Reshipment .....	1-7, 1-8	4-1. Introduction .....	4-1
<b>SECTION 2-INSTALLATION</b>			
2-1. Unpacking and Handling .....	2-1	a. Symptom Recognition .....	4-1
2-2. Power Requirements .....	2-1	b. Symptom Elaboration .....	4-1
2-3. Cabinet Model AN/USM-140B Installation .....	2-2	c. Determining Probable Faulty Section .....	4-1
2-4. Rack Model AN/USM-141 Installation .....	2-2	d. Locating the Faulty Circuit .....	4-1
2-5. Cables and Connectors .....	2-3	e. Localizing the Faulty Circuit .....	4-1
a. Power Cable .....	2-3	f. Failure Analysis .....	4-1
b. Test Prods .....	2-3	g. Test Equipment Required for Trouble Shooting .....	4-1
2-6. The CRT Bezel, Graticule and Filter .....	2-4	4-2. Overall Oscilloscope .....	4-1
2-7. Initial Electrical Inspection .....	2-4	a. Functional Description of Oscilloscope .....	4-1
<b>SECTION 3-OPERATION</b>			
3-1. Functional Operation .....	3-1	b. Low-Voltage Power Supplies .....	4-1
3-2. Preparation for Use .....	3-1	c. High-Voltage Power Supplies .....	4-1
		d. Beam Finder Circuit .....	4-1
		e. Main Vertical Amplifier .....	4-1
		f. Horizontal Amplifier .....	4-1
		g. Sweep Generator .....	4-1
		h. MX-3078/USM Horizontal Plug-In .....	4-3



SECTION 6--PREVENTIVE MAINTENANCE  
CHECKS AND SERVICES

Paragraph	Page
APPENDIX I. References .....	A1-1
II. BASIC ISSUE ITEMS LIST (BIIL) and ITEMS TROOP INSTALLED OR AUTHORIZED LIST (ITIAL)	
SECTION I. Introduction .....	A2-1
II. Basic issue items list ....	A2-2
III. Items troop installed or authorized list (Not applicable)	
APPENDIX III. Maintenance Allocation Chart .....	A3-1

Paragraph	Page
6-1. Scope of Maintenance .....	6-1
6-2. Preventive Maintenance .....	6-1
6-3. Preventive Maintenance Checks and Services Periods .....	6-1
6-4. Daily Preventive Maintenance Checks and Services Chart .....	6-3
6-5. Weekly Preventive Maintenance Checks and Services Chart .....	6-4
6-6. Monthly Preventive Maintenance Checks and Services Chart .....	6-4
6-7. Quarterly Preventive Maintenance Checks and Services Chart .....	6-5
6-8. Cleaning .....	6-7
6-9. Touchup Painting Instructions .....	6-7

Change 3 iv.1

## LIST OF ILLUSTRATIONS

Figure		Page	Figure	Page
SECTION 1 - GENERAL DESCRIPTION			SECTION 4 - TROUBLE SHOOTING (Cont)	
1-1.	Oscilloscope AN/USM-140B .....	1-0	4-9.	Horizontal Amplifier Functional and Servicing Block Diagram .....
SECTION 2 - INSTALLATION			4-33, 4-34	
2-0.	Exploded View of Supply Package for AN/USM-140B Oscilloscope ....	2-0	4-10.	Schmitt Trigger Simplified Circuit with Waveforms .....
2-1.	Power Connections for Operating the Oscilloscope on 230-volt Power Line .....	2-1	4-11.	Sweep Generator Functional and Servicing Block Diagram .....
2-2.	AN/USM-140B Dimensions .....	2-2	4-12.	Construction of Vertical Plug-In Extender 162A-39A .....
2-3.	AN/USM-141 Dimensions .....	2-3	4-13.	Vertical Plug-In Functional and Servicing Block Diagram .....
SECTION 3 - OPERATION			4-45, 4-46	
3-1.	Oscilloscope Front-Panel Controls and Connectors . .....	3-2	4-14.	Bottom View, Location of Test Points on Low-Voltage Power Supply .....
3-2.	Procedure for Turning On Oscilloscope ,Compensating Probe, and Making Initial Electrical Inspection .....	3-4	4-15.	Top View, Location of Test Points on High-Voltage Power Supply .....
3-3.	Selecting and Synchronizing the Sweep and Sweep Magnifications .	3-6	4-16.	Bottom View, Location of Test Points on Horizontal Pre-amplifier Assembly .....
SECTION 4 - TROUBLE SHOOTING			4-49	
4-1.	Overall Functional Block Diagram ..	4-2	4-17.	Top View, Location of Test Points on Main Horizontal Amplifier and Divider Assembly .....
4-2.	Overall Servicing Block Diagram ....	4-6	4-18.	Bottom View, Location of Test Points on Sweep Generator Assembly .....
4-3.	Low-Voltage Power Supply Functional and Servicing Block Diagram .....	4-13, 4-14	4-19.	Top View, Location of Test Points on Main Vertical Amplifier Assembly .....
4-4.	High-Voltage Power Supply Functional and Servicing Block Diagram .....	4-19, 4-20	4-20.	Fan Shroud and Power Transistor Assembly, Location of Test Points and Connections .....
4-5.	Simplified Schematic Diagram of the Beam Finder Circuit .....	4-18	4-21.	Left Side View of MX-2930B/USM Vertical Plug-In Assembly, Location of Test Points .....
4-6.	Cascode Amplifier/Simplified Schematic Diagram and Cross-Coupled Cathode Follower .....	4-22	4-22.	Right Side View of MX-2930B/USM, Location of Test Points .....
4-7.	Constant Current Generator Simplified Schematic Diagram .....	4-23	4-54	
4-8.	Main Vertical Amplifier Functional and Servicing Block Diagram .....	4-27, 4-28	4-54	

## LIST OF ILLUSTRATIONS (Cont)

Figure	Page	Figure	Page
SECTION 5 - MAINTENANCE		SECTION 5 - MAINTENANCE (Cont)	
5-1.	Main Vertical Amplifier Test Connector ..... 5-2	5-25.	Calibrator Switch Assembly, Location of Parts ..... 5-41
5-2.	Location of Low-Voltage Power Supply Adjustments ..... 5-10	5-26.	High-Voltage Power Supply Etched Circuit Assembly, Location of Parts ..... 5-43
5-3.	Top View, Location of Adjustments ..... 5-11	5-27.	High Voltage Distribution Etched Circuit Assembly, Location of Parts ..... 5-45
5-4.	Bottom View, Location of Adjustments ..... 5-13	5-28.	Low Voltage Rectifier Etched Circuit Assembly, Location of Parts ..... 5-46
5-5.	Location of Adjustments in MX-2930B/USM ..... 5-16	5-29.	Low Voltage Regulator Amplifier Etched Circuit Assembly, Location of Parts ..... 5-47, 5-48
5-6.	Top and Bottom Views, Location of Electron Tubes ..... 5-18	5-30.	MX-2930B/USM, Location of Parts ..... 5-49
5-7.	Removal of Cathode-Ray Tube ..... 5-19	5-31.	MX-2930B/USM Dual Channel Vertical Amplifier Etched Assembly, Location of Parts ..... 5-51
5-8.	Wiring Between Switch S202 and Etched Circuit Board A201 ..... 5-20	5-32.	MX-2930B/USM Vertical Switching Etched Circuit Assembly, Location of Parts ..... 5-53
5-9.	Top View, Location of Parts ..... 5-24	5-33.	MX-2930B/USM Vernier/Sensitivity Switch Assembly, Location of Parts ..... 5-54
5-10.	Bottom View, Location of Parts ..... 5-25	5-34.	MX-2930B/USM Vertical Presentation Switch Assembly, Location of Parts ..... 5-55
5-11.	Right-Side View, Location of Parts ..... 5-26	5-35.	MX-2817/U Test Prod, Location of Replaceable Parts ..... 5-56
5-12.	Left-Side View, Location of Parts ..... 5-27	5-36.	MX-3078/USM Horizontal Auxiliary Plug-In Unit, Location of Parts ..... 5-57
5-13.	Front-View, Location of Parts ..... 5-27	5-37.	Main Vertical Amplifier Schematic Diagram ..... 5-59, 5-60
5-14.	Main Vertical Input Amplifier and Internal Sync Source Etched Circuit Assembly, Location of Parts ..... 5-29	5-38.	Sweep Generator Schematic Diagram ..... 5-61, 5-62
5-15.	Main Vertical Amplifier and Driver Etched Circuit Assembly ..... 5-31	5-39.	Sweep-Time Switch, Functional Schematic Diagram ..... 5-63, 5-64
5-16.	Scanner Output Etched Circuit Assembly, Location of Parts ..... 5-32	5-40.	Sweep-Time Switch, Wiring Diagram ..... 5-65, 5-66
5-17.	Sweep Generator Etched Circuit Assembly, Location of Parts ..... 5-33	5-41.	Horizontal Amplifier Schematic Diagram ..... 5-67, 5-68
5-18.	Sweep Time Switch Assembly, Location of Parts ..... 5-34	5-42.	Horizontal Display Switch Schematic Diagram ..... 5-69, 5-70
5-19.	Sweep Mode/Trigger Source Switch Assembly, Location of Parts ..... 5-34	5-43.	High-Voltage Power Supply and Calibrator Schematic Diagram ..... 5-71, 5-72
5-20.	Trigger Level/Trigger Slope Switch Assembly, Location of Parts ..... 5-34	5-44.	Low-Voltage Power Supply Schematic Diagram ..... 5-73, 5-74
5-21.	Ext. Vernier/Horizontal Display Switch Assembly, Location of Parts ..... 5-35, 5-36	5-45.	Electron Tube Heater Circuit, Functional Diagram ..... 5-57, 5-75
5-22.	Horizontal Sensitivity Adjustment Etched Circuit Assembly, Location of Parts ..... 5-37	5-46.	MX-2930B/USM Dual-Trace Preamplifier Schematic Diagram ..... 5-77, 5-78
5-23.	Main Horizontal Amplifier and Driver Etched Circuit Assembly, Location of Parts ..... 5-39, 5-40		
5-24.	Horizontal Impedance Matching Preamp Etched Circuit Assembly, Location of Parts ..... 5-41		

## LIST OF ILLUSTRATIONS (Cont)

Figure		Page	Figure		Page
SECTION 5 - MAINTENANCE (Cont)			SECTION 5 - MAINTENANCE (Cont)		
5-47.	MX-3078/USM Horizontal Channel Auxiliary Plug-In Unit Schematic Diagram .....	5-79	5-48.	Connections to the Horizontal and Vertical Plug-In Connectors J105 and J1 .....	5-80
LIST OF TABLES					
Table		Page	Table		Page
SECTION 1 - GENERAL DESCRIPTION			SECTION 5 - MAINTENANCE		
1-1.	Equipment Supplied with Oscilloscope AN/USM-140B .....	1-3	5-1.	Reference Standards Procedures .....	5-2
1-2.	Equipment and Publications Required but not Supplied .....	1-4	5-2.	Test Equipment for Reference Standards Procedures .....	5-2
1-3.	Accessories for Oscilloscope AN/USM-140B .....	1-7, 1-8	5-3.	Power Supply Reference Standards Procedures .....	5-3
SECTION 3 - OPERATION			5-4.	Calibrator Reference Standards Procedures .....	5-4
3-1.	Description of Front-Panel Controls and Connectors .....	3-2	5-5.	Horizontal Amplifier Reference Standards Procedures .....	5-5
3-2.	Procedure for Turning On Oscilloscope and Preparing it for Use .....	3-4	5-6.	Sweep Generator Reference Standards Procedures .....	5-6
3-3.	Selecting and Synchronizing the Sweep and Sweep Magnification ...	3-6	5-7.	Main Vertical Amplifier Reference Standards Procedures .....	5-7
3-4.	Adjustments Required Following Tube and Semiconductor Replacement .....	3-10	5-8.	MX-2930B/USM Vertical Plug-In..... Reference Standards Procedures .....	5-7 5-8
SECTION 4 - TROUBLE SHOOTING			5-9.	Test Equipment for Adjustment Procedures Reference Standards Procedures .....	5-10
4-1.	Test Equipment Required for Trouble Shooting .....	4-3	5-10.	Sweep Calibration Reference Standards Procedures .....	5-14
4-2.	Overall Oscilloscope Trouble Shooting .....	4-4	SECTION 6 - PARTS LIST		
4-3.	Low-Voltage Power Supply Trouble Shooting .....	4-8	6-1.	List of Units .....	6-1
4-4.	High-Voltage Power Supply Trouble Shooting .....	4-16	6-2.	Maintenance Parts List .....	6-2
4-5.	Main Vertical Amplifier Trouble Shooting .....	4-23	6-3.	List of Manufacturers .....	6-27
4-6.	Horizontal Amplifier Trouble Shooting .....	4-30			
4-7.	Sweep Generator Trouble Shooting .....	4-37			
4-8.	Calibrator Circuit Trouble Shooting .....	4-41			




Figure 1-1. Oscilloscope AN/USM-140B

## SECTION A INTRODUCTION

---

### A-1. Indexes of Publications

a. *DA Pam 310-4*. Refer to the latest issue of DA Pam 310-4 to determine whether there are new editions, changes, or additional publications pertaining to the equipment.

b. *DA Form 310-7*. Refer to DA Pam 310-7 to determine whether there are modification work orders (MWO's) pertaining to the equipment.

### A-2. Forms and Records

a. *Reports of Maintenance and Unsatisfactory Equipment*. Maintenance forms, records, and reports which are to be used by maintenance personnel at all maintenance levels are listed in and prescribed by TM 38-750.

b. *Report of Packaging yard Handling Deficiencies*. Fill out and forward DD Form 6 (Report of Packaging and Handling Deficiencies)

as prescribed in AR 700-58/NAVSUP PUB 378/AFR 71-4/MCO P4030.29, and DSAR 4145.8.

c. *Discrepancy in Shipment Report (DISREP) (SF 361)*. Fill out and forward Discrepancy in Shipment Report (DISREP) (SF 361) as prescribed in AR 55-38/NAVSUPINST 4610.33/AFM 75-18/MCO P4610.19A, and DSAR 4500.15.

### A-3. Reporting of Errors

The reporting of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Changes to Publication and Blank Forms) and forwarded direct to Commander, UIS Army Electronics Command, ATTN: AMSEL-MA-C, Fort Monmouth, NJ 07703.

AN/USM-140B  
GENERAL DESCRIPTION

UNCLASSIFIED  
NAVSHIPS 0967-133-7010

**SECTION I  
GENERAL DESCRIPTION**

**1-1. SCOPE**

NAVSHIPS 95706 is a single-volume technical manual that includes operating and servicing instructions and a list of replaceable parts prepared in accordance with MIL-M-15071 E (SHIPS) for Oscilloscopes AN/USM-140B, AN/USM-140C, AN/USM-141A, and AN/USM-141B. The electrical specifications, operating and servicing instructions, schematic diagrams and parts list are identical for all models with noted exceptions. The AN/USM-140B and AN/USM-140C are portable models for benchtop use; the AN/USM-141A and AN/USM-141B are designed for permanent installation in a standard 19-inch wide rack. No other publications are required or supplied for these oscilloscopes at the date of this publication. Subsequent references to the Oscilloscopes in this manual will list only the cabinet model AN/USM-140B except to indicate minor differences in details.

**1-1.1. Items Comprising an Operable Equipment**

<i>FSN</i>	<i>Qty</i>	<i>Nomenclature</i>
6625-987-6603		Oscilloscope AN/USM-140B consisting of:
6625-400-2681	1	Oscilloscope OS-121B/USM-140
	1	Preamplifier, Dual Trace MX-2930B/USM (Plugged into OA-121/USM-140)
6625-961-5888	1	Auxiliary Plug-In MX-3078/USM (Plugged into OS-121/USM-140)
6625-973-4775	2	Prod, Test MX-4073/U (Mounted in equipment)
5935-823-0639	2	Connector, Adapter UG-255A/U (Mounted in equipment)
5935-149-3534		Connector, Adapter UG-273/U (Mounted in equipment)

<i>FSN</i>	<i>Qty</i>	<i>Nomenclature</i>
5995-985-7744		Cable Assembly, Power, Electrical CX-4704/U (8 ft 0 in.) (Mounted in equipment)
5995-752-8781	2	Cord CG-409F/U (Mounted in equipment)
5935-683-7892	2	Connector, Adapter: MIL type MS35173-274B (Mounted in equipment)
4935-992-6112	4	Adapter, Connector UG-1441/U

**1-2. General Description**

The AN/USM-140B is a precision high-speed oscilloscope for displaying the waveforms of electrical voltages at frequencies ranging from direct current to 22 megacycles (equivalent to a risetime of 16 nanoseconds). Vertical deflection sensitivity is continuously adjustable from 200 volts to 20 millivolts per centimeter; horizontal deflection sensitivity is continuously adjustable from 100 volts to 0.1 volt per centimeter at frequencies from direct current to 1 megacycle per second. Sweep rates are continuously adjustable from 15 seconds to 0.1 microsecond per centimeter. The sweep can be synchronized with an external signal or with the signal being viewed. Polarity and sensitivity of the synchronization are selectable to permit synchronization from different voltage points on complex waveforms. The AN/USM-140B is especially developed for general-purpose use in US Navy ship and shore electronic maintenance and research facilities. It is designed for versatility, and reliability under a wide range of environmental conditions, combined with wide frequency range, accurate calibration, and stable synchronization at high sweep rates. Sweep rate, sweep expansion and sensitivity controls are direct-reading. Each calibrated step-type control is equipped with a potentiometer to give