

# **TM 11-6625-539-15-2**

**DEPARTMENT OF THE ARMY TECHNICAL MANUAL**

---

**OPERATOR, ORGANIZATIONAL DS, GS,  
AND DEPOT MAINTENANCE MANUAL**

**TEST SET,  
TRANSISTOR TS-1836B/U**

This copy is a reprint which includes current  
pages from Changes 1 through 3. Title  
was changed by Change 3.

---

**HEADQUARTERS, DEPARTMENT OF THE ARMY**

**04 OCTOBER 1968**

**TECHNICAL MANUAL**  
**No. 11-6625-539-15-2**


**HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, D.C., 4 October 1968**

**OPERATOR, ORGANIZATIONAL DIRECT SUPPORT, GENERAL SUPPORT,  
AND DEPOT MAINTENANCE MANUAL  
INCLUDING REPAIR PARTS AND SPECIAL TOOL LISTS**

**TEST SET, TRANSISTOR TS-1836B/U**

	Paragraph	Page
<b>CHAPTER 1.</b>		
<b>Section I.</b>		
INTRODUCTION		
General		
Scope .....	1-1	1-1
Indexes of publications .....	1-2	1-1
Forms and records .....	1-3	1-1
Reporting of errors .....	1-3.1	1-1
Reporting equipment improvement recommendations .....	1-3.2	1-1
Administrative storage .....	1-3.3	1-1
Destruction of Army electronics materiel .....	1-3.4	1-1
II.		
Description and data		
Description and use .....	1-4	1-1
Technical characteristics .....	1-5	1-2
Items comprising an operable Test Set, Transistor		
TS-1836B/U .....	1-6	1-3
<b>CHAPTER 2.</b>		
<b>INSTALLATION</b>		
Unpacking .....	2-1	2-1
Checking unpacked equipment .....	2-2	2-1
Cable connections .....	2-3	2-1
<b>3. OPERATING INSTRUCTIONS</b>		
General .....	3-1	3-1
Preliminary operating instructions .....	3-2	3-1
Controls and indicators .....	3-3	3-1
Operating .....	3-4	3-1
Methods for servicing semiconductors circuitry .....	3-5	3-4
Determining types of failures .....	3-6	3-4
<b>4. OPERATOR'S AND ORGANIZATIONAL MAINTENANCE</b>		
Scope of maintenance .....	4-1	4-1
Preventive maintenance .....	4-2	4-1
Preventive maintenance checks and services periods .....	4-3	4-1
Operator's daily preventive maintenance checks and services chart .....	4-4	4-2
Operator's weekly preventive maintenance checks and services chart .....	4-5	4-2
Organizational monthly preventive maintenance checks and services chart .....	4-6	4-2
Cleaning .....	4-7	4-2
Rustproofing and painting .....	4-8	4-2
<b>5. CIRCUIT FUNCTIONING</b>		
Introduction .....	5-1	5-1
Battery .....	5-2	5-1
Beta and diode in-circuit checks .....	5-3	5-1
OHMS E-B, C-B, and C-E resistance checks .....	5-4	5-2
Leakage ICO X1 and X10 check .....	5-5	5-2
DIODE 1-10 ratio check .....	5-6	5-2
F.E.T. CAL check .....	5-7	5-3
F.E.T. READ check .....	5-8	5-4
<b>6. TROUBLESHOOTING AND REPAIR</b>		
Troubleshooting techniques .....	6-1	6-1
Troubleshooting chart .....	6-2	6-2
<b>7. ALIGNMENT PROCEDURES</b>		
General .....	7-1	7-1
Alignment of meter zero .....	7-2	7-1
Alignment of meter OHMS position .....	7-3	7-1
Alignment of meter F.E.T. position .....	7-4	7-2

	Paragraph	Page
<b>CHAPTER 8. GENERAL SUPPORT TESTING PROCEDURES</b>		
General .....	8-1	8-1
Test equipment and material .....	8-2	8-1
Modification work orders .....	8-3	8-1
Physical tests and inspection .....	8-4	8-1
Meter OHMS position test .....	8-5	8-2
Test set F.E.T. position test .....	8-6	8-2
<b>9. DEPOT OVERHAUL STANDARDS</b>		
Applicability of depot overhaul standards .....	9-1	9-1
Applicable references .....	9-2	9-1
Test facilities required .....	9-3	9-1
Depot overhaul standards tests .....	9-4	9-1
<b>10. SHIPMENT AND LIMITED STORAGE AND DEMOLITION TO PREVENT ENEMY USE</b>		
Section I. Shipment and limited storage .....	10-1	10-1
Disassembly of equipment .....	10-2	10-1
Repackaging for shipment or limited storage .....	10-3	10-1
II. Demolition of materiel to prevent enemy use .....	10-4	10-2
Authority for demolition .....	A-1	
Methods of destruction .....	C-1	
<b>APPENDIX A. REFERENCES .....</b>		
<b>B. BASIC ISSUE ITEMS LIST (BIIL) AND ITEMS TROOP INSTALLED OR AUTHORIZED LIST (ITIAL) (Not Applicable)</b>		
<b>C. MAINTENANCE ALLOCATION</b>		
Section I. Introduction .....	C-3	
II. Maintenance allocation chart.....	C-3	
<b>APPENDIX D. DELETED</b>		
<b>E. TRANSISTOR CHARACTERISTICS DATA FOR TEST SET, TRANSISTOR TS-183613/U.....</b>	E-1	



TM6625-539-15-2-1

Figure 1-1. Test set, Transistor TS-1836B/U.

## 1-6. Items Comprising an Operable Test Set, Transistor TS-1836B/U

FSCM	QTY	<i>No modification, part No., and info code</i>
<b>NOTE</b>		
The part number is followed by the applicable 5-digit Federal supply code for manufacturers (FSCM) identified in SB 706-42 and used to identify manufacturer, distributor, or Government agency, etc.		
<b>NOTE</b>		
Dry batteries shown are used with the equipment but are not considered part of the equipment. They will not be preshipped automatically but are to be requisitioned in quantities necessary for the particular organization in accordance with SB 11-6.		
6625-813-9205	1	Test Set, Transistor TS-1836B/U which includes:
6625-813-9205	1	Cover, Test Set 4252193-503, 24624
6135-120-1010		Battery, Dry BA-42
	1	Lead, Test 22801905, 93346
	1	Lead, Test 2280190-6, 93346
	1	Lead, Test 2280190-7, 93346

## CHAPTER 2

### INSTALLATION

---

#### 2-1. Unpacking

*a. Packaging Data.* When packed for shipment, Test Set, Transistor TS-1836B/U is placed in a waterproof carton and packed in a wooden packing case. A typical packing case and its contents are shown in figure 2-1.

*b. Removing Contents (Wooden Packing Case).* Perform all the procedures in (1) through (5) below when unpacking equipment packed in a wooden packing case (fig. 2-1).

- (1) Cut and fold back the metal straps.

***Caution: Do not attempt to pry off the sides; this may damage the equipment.***

(2) Remove the nails from the cover and one side of the wooden packing case with a nailpuller. Remove the cover and one side.

(3) Open the moistureproof barrier that covers the outer corrugated carton. Remove the carton.

(4) Open the outer corrugated carton and the moisture-vaporproof barrier within the carton. Remove the inner corrugated carton.

(5) Open the inner corrugated carton, and remove the instrument.

#### 2-2. Checking Unpacked Equipment

*a. Inspect the equipment for damage incurred during shipment.*

*b. Check to see that the equipment is complete. The equipment is normally shipped less the batteries. Report all discrepancies in accordance with TM 38-750. Shortage of a minor assembly or part that does not affect proper functioning of the equipment should not prevent use of the equipment.*


*c. If the equipment has been used or reconditioned, see whether it has been changed by a modification work order (MWO). If the equipment has been modified, the MWO number will appear on the side near the nomenclature plate. Check to see whether the MWO number (if any) and appropriate notations concerning the modification have been entered in the equipment manual.*

*Note. Current MWO's applicable to the equipment are listed in DA Pam 310-7.*

#### 2-3. Cable Connections

No cable connections are necessary for operation of the test set other than the three accessory test leads. Connect the three accessory test leads as follows:

- a. Insert the red plug into the red jack.*
- b. Insert the black plug into the black jack.*
- c. Insert the yellow plug into the yellow jack.*



TM 6625-539-15-2-15

Figure 2-1. Typical packaging diagram.