

TECHNICAL MANUAL

**ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT
MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)
FOR**

TEST SET, TRANSISTOR TS-1836B/U

(NSN 6625-00-168-0954)



**ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT
MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)
FOR
TEST SET, TRANSISTOR TS-1836B/U
(NSN 6625-00-168-0954)**

Current as of 28 April 1976

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 2028-2 (Test) located in the back of the manual. Simply tear out the self addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Form 2028-2 (Test) in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Electronics Command, ATTN: DRSEL-MA-Q, Fort Monmouth, New Jersey 07703.

In either case a reply will be furnished direct to you.

	Page	Illus Figure
Section I. Introduction - - - - -	1	
II. Repair parts list - - - - -	5	
Group 00 Test Set, Transistor TS-1836B/U - - - - -	5	1
01 Case Assembly (Upper) - - - - -	6	2
02 Panel Assembly - - - - -	9	3-5
0201 Electronic Components Assembly - - - - -	15	6
03 Case Assembly (Lower) - - - - -	17	7
Section III. Special tool list (Not applicable)		
IV. National stock number and part number index - - - - -	18	

*This manual supersedes so much of TM 11-6625-539-15-2, 4 October 1968, as pertains to repair parts and special tools list.

SECTION 1

INTRODUCTION

1. Scope

This manual lists repair parts and special tools required for performance of general support maintenance of the TS-1836B/U.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. *Section 11. Repair Parts List.* A list of repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending numerical sequence, with the parts in each group listed in figure and item number sequence.

b. *Section III. Special Tools List.* Not applicable.

c. *Section IV. National Stock Number and Part Number Index.* A list, in ascending National item identification number (NIIN, last 9 digits) sequence, of all National stock numbers appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock number and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

The following provides an explanation of columns found in the tabular listings:

a. *Illustration.* This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration in which the item is shown.

(2) *item number.* The number used to identify each item called out in the illustration.

b. *Source, Maintenance, and Recoverability Codes (SMR).*

(1) *Source code.* Source codes are assigned to support items to indicate the manner of acquiring support items for maintenance, repair,

or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

<i>Code</i>	<i>Definition</i>
-------------	-------------------

PA—Item procured and stocked for anticipated or known usage.	
--------------------------------------------------------------	--

XD—A support item that is not stocked. When required, item will be procured through normal supply channels.	
-------------------------------------------------------------------------------------------------------------	--

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA, XD, and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

<i>Code</i>	<i>Application /Explanation</i>
-------------	---------------------------------

H—Support item is removed, replaced, used at the general support level.	
-------------------------------------------------------------------------	--

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:	
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

<i>Code</i>	<i>Application /Explanation</i>
-------------	---------------------------------

H—The lowest maintenance level capable of complete repair of the support item is the general support level.	
-------------------------------------------------------------------------------------------------------------	--

Z—Nonreparable. No repair is authorized.	
------------------------------------------	--