

TECHNICAL MANUAL

**ORGANIZATIONAL, DIRECT SUPPORT,
AND GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LISTS
(INCLUDING DEPOT MAINTENANCE REPAIR
PARTS AND SPECIAL TOOLS)**

FOR

MAINTENANCE KIT

MK-1035/ARC-131

(NSN 5821-00-935-0058)

HEADQUARTERS, DEPARTMENT OF THE ARMY

MARCH 1977

TECHNICAL MANUAL

No. 11-6625-1610-24P



HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, 15 March 1977

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LISTS

(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)

FOR

MAINTENANCE KIT MK-1035/ARC-131

(NSN 5821-00-935-0058)

Current as of 28 November 1976

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 2028-2 (Test) located in the back of the manual. Simply tear out the self-addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Forms 2028-2 (Test) in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Electronics Command, ATTN: DRSEL-MA-Q, Fort Monmouth, New Jersey 07703.

In either case a reply will be furnished direct to you.

Table of Contents

		Page	Illus Figure
Section	I. Introduction	1	
	II. Repair parts list	5	
Group	00 Maintenance Kit, Electronic Equipment MK-1035/ARC-131	5	1
	01 Cable Assembly, Special Purpose CX-10569/ARC-131	7	2
	02 Cable Assembly, Radio Frequency CG-3370/U (W8)	8	3
	03 Cable Assembly, Radio Frequency CG-3370/U (W6)	9	4
	04 Cable Assembly, Special Purpose CX-10570/U (W1)	10	5
	05 Cable Assembly, Special Purpose CX-10572/U (W3)	11	6
	06 Cable Assembly, Special Purpose CX-10573/U (W4)	12	7
	07 Cable Assembly, Radio Frequency CG-3374/U (W11)	13	8
	08 Cable Assembly, Radio Frequency CG-3375/U (W12)	14	9
	09 Cable Assembly, Power Electrical CX-10575/U (W16)	15	10
	10 Cable Assembly, Radio Frequency CG-3371/U (W7)	16	11
	11 Cable Assembly, Radio Frequency CG-3376/U (W15)	17	12
	12 Cable Assembly, Special Purpose CX-10574/ARC-131	18	13
	13 Cable Assembly, Radio Frequency CG-3372/U (W17)	19	14
	14 Cable Assembly, Radio Frequency CG-3373/U (W9)	20	15
	15 Cord Assembly, Electrical CX-10576/U (W8)	21	16
	16 Cable Assembly, Special Purpose CX-10571/U (W2)	22	17
	17 Case, test set	23	18

*This manual supersedes TM 11-6625-1610-20P-2 November 1979, and TM 11-6625-1610-34P-11 December 1973.

TM 11-6625-1610-24P

	Page	Illus Figure
18 Variable Attenuator TG-950	25	19
19 Simulator, Antenna SM-499/ARC-131	27	20
20 Test Set, Radio TS-2575/ARC-131	29	21-25
2001 Power supply	43	26
2002 Audio amplifier	45	27
2003 Control, Radio Set C-7088/ARC-131 (See TM 11-5820-670-20P and TM 11-5820-670-34P for parts)		
2004 Control, Intercommunication Set C-1611(*)/A1C (See TM 11-5831-201-20P and TM 11- 5831-201-35P for parts)		
2005 Indicator ID-48/ARN (No parts authorized)		
Section III. Special tools List (Not applicable)		
IV National stock number and part number index	46	

SECTION I

INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational, direct support and general support maintenance of the MK-1035/ARC-131.

It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. *Section II. Repair Parts List.* A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. *Section III. Special Tools List.* Not applicable.

c. *Section IV. National Stock Number and Part Number Index.* A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphanumeric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of columns

a. *Illustration.* This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* The number used to identify item called out in the illustration.

b. *Source, Maintenance, and Recoverability (SMR) Codes.*

(1) *Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code

Definition

PA-Item procured and stocked for anticipated or known usage.

XD-A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code

Application/Explanation

O- Support item is removed, replaced, used at the organizational level.

F- Support item is removed, replaced, used at the direct support level.

D - Support items that are removed, replaced, used at depot, mobile depot, specialized repair activity only.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code

Application/Explanation

F- the lowest maintenance level capable of complete repair of the support item is the direct support level.

D- The lowest maintenance level capable of complete repair of the support item is the depot level.

Z - Non repairable. No repair is authorized.