

TECHNICAL MANUAL

**ORGANZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT
MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS
(INCLUDING DEPOT MNTENANCE REPAIR PARTS AND SPECIAL TOOLS)**

FOR

**TEST SET, ELECTRONIC SYSTEM AN/ASM-338
(NSN 6625-00-878-7990)**

HEADQUARTERS, DEPARTMENT OF THE ARMY

JULY 1976

1-TS 4828-----

**ORGANIZATIONAL, DIRECT SUPPORT, AND
GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)
FOR
TEST SET, ELECTRONIC SYSTEM AN/ASM-338
(NSN 6625-0 877990)**

Current as of 1 January 1976

REPORTING OF ERRORS
You can improve this manual by recommending improvements using DA Form 2028-2 (Test) located in the back of the manual. Simply tear out the self addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.
If there are no blank DA Form 2028-2 (Test) in the back of your manual use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Electronics Command, ATTN: DRSELMA-Q, Fort Monmouth, New Jersey 07703. In either case a reply will be furnished direct to you.

		Page	Illustration Figure
Section	I. Introduction	1	
	II. Repair parts	5	
Group	00 Test Set, Electronic System AN/ASM338	5	1
	01 Test Set, Electronic System TS-2676/ASM-338	7	2-4
	0101 Circuit card assembly	13	5
	02 Case, test set.	15	6
	0201 Cable Assembly, Special Purpose CX1081/U.....	17	7
	0202 Cable Assembly, Special Purpose CX10852/U (No parts authorized)		
	0203 Cable Assembly, Special Purpose CX10853/U.....	19	8
	0204 Cable Assembly, Special Purpose CX10854/U.....	21	9
	0205 Board Assembly, Extender MX8096/ASM338.....	23	10
Section	III. Special tools lists (Not applicable)		
	IV. National stock number and parts number index.....	24	

*This manual supersedes so much of TM-6625-1704-15, 29 March 1968, as pertains to repair parts and special tools list .

**SECTION I
INTRODUCTION**

1. Scope

This manual list repair parts and special tools required for performance of organizational, direct support, and general support maintenance of the AN/ASM338.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II-Repair Parts List. A list of repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending numerical sequence, with the parts in each group listed in figure and item number sequence.

b. Section III Special Tools List. Not applicable.

c. Section IV National Stock Number and Part Number Index. A list, in ascending National item identification number (NIIN, last 9 digits) sequence, of all National stock numbers appearing in the listings, followed by a list, in alphanumeric sequence, of all part numbers appearing in the Listing. National stock number and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

The following provides an explanation of columns found in the tabular listings:

a. *Illustration.* This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration in which the item is shown.

(2) *Item number.* The number used to identify each item called out in the illustration.

b. *Source, Maintenance, and Recoverability Codes (SMR).*

(1) *Source code.* Source codes are assigned to

support items to indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

<i>Code</i>	<i>Definition</i>
PA	Item procured and stocked for anticipated or known usage.
XA	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XD	A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA, XD, and aircraft support items as restricted by AR 70042.

(2) Maintenance code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

<i>Code</i>	<i>Application/Explanation</i>
O	Support item is removed, replaced, used at the organizational level.
H	Support item is removed, replaced, used at the general support level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete