

**TECHNICAL MANUAL**

**ORGANIZATIONAL, DIRECT SUPPORT AND**

**GENERAL SUPPORT MAINTENANCE**

**REPAIR PARTS AND SPECIAL TOOLS LISTS**

**(INCLUDING DEPOT MAINTENANCE REPAIR**

**PARTS AND SPECIAL TOOLS)**

**FOR**

**TEST SET GROUP, PROCESSOR, RADAR**

**OQ-61 / APS-94D**

( N S N 6 6 2 5 - 0 0 - 9 3 8 - 0 2 3 3 )

**HEADQUARTERS, DEPARTMENT OF THE ARMY**

**MARCH 1976**

TECHNICAL MANUAL }  
 No. 11-6625-1832-24P }

HEADQUARTERS  
 DEPARTMENT OF THE ARMY  
 WASHINGTON, D.C., 8 March 1976

**ORGANIZATIONAL, DIRECT SUPPORT AND  
 GENERAL SUPPORT MAINTENANCE  
 REPAIR PARTS AND SPECIAL TOOLS LISTS  
 (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)  
 FOR  
 TEST SET GROUP, INDICATOR, RADAR 0Q-61/APS-94D**

(NSN 6625-00-938-0233)

Current as of 15 August 1975

SECTION		Page	Illustration Figure
SECTION	I Introduction	1	
SECTION	II Repair parts list	5	
Group	00 Test Set Group, Processor, Radar OQ-61/APS-94D	5	1
	01 Interface Test. Processor, Radar TS-2973/APS-94D	5	2
	0101 Panel, test, electrical	5	3
	010101 Clock and counter module LA1	9	4
	010102 Oscillator and switch module IA2	13	5
	010103 Power supply regulator module IA3	15	6
	010104 Electronic components assembly ITB1	18	7
	02 Interface Test. Electronic Circuit Plug-in Unit TS-2972/APS-94D	18	8
	0201 Panel, test, electrical	22	9
	020101 Comparator 2A1	25	10
	020102 Frequency filters and control gates 2A2	29	11
	020103 Frequency synthesizer 2A3	31	12
	020104 Control logic 2A4	34	13
	020105 Fault detector 2A5	34	14
	020106 X-Select control 2A6	34	15
	020107 Y-Coordinate select 2A7	34	16
	020108 Plus and minus 5-volt post regulator 26A11	39	17
	020109 Plus and minus 5-volt 2-ampere regulator 2A12	39	18
	020110 Regulator 2A13	42	19
	020111 Power supply 2A14	45	20
	03 Interface Test Power Supply TS 2971/APS-94D	45	21
	0301 Power supply control 3A1	48	22
	030101 Function control module 3A1A1	50	23
	030102 Power supply module 3A1A2	55	24
	030103 Heat exchanger assembly	57	25
	0302 Power supply, dummy load 3A2	57	26
	030201 Positive load control module 3A2A1	57	27
	030202 Negative load control module 3A2A2	62	28
	030203 Switching module 3A2A3	64	29
	030204 Electronic components assembly	64	30
	04 Interface Test, Synchronizer, Radar TS-2970/APS 94D	64	31
	0401 Interface Test Subassembly MX 8679/APS 94D	70	32
	040101 Panel test. electrical	70	33
	04010101 BCD up-down counter and thumbwheel multiplexer module 4A16	73	34
	04010102 BCD to decimal lamp driver modules 4A17 and 4A18	77	35

\*This manual supersedes TM 11-6625-1832-4OP, 6 June 1972

	Page	Illustration Figure
Repair parts list - Continued		
04010103 BCD to binary converter module 4A19	77	36
01010104 Mode control module 4A20	77	37
04010105 PRP and antenna counter module 4A21	81	38
04010106 Plus and minus 5 volt 2-ampere regulator module 4A22	81	18
04010107 Regulator 4A23	81	19
04010108 Bite module 4A24	81	39
<b>0402</b> Interlace Subassembly MX 8680/APS-94D	85	40
040201 Test Adapter MX-8615/APS-94D	85	41
04020101 32 channel multiplexer 4A1A1	85	42
04020102 Buffer driver 4A1A2	90	43
04020103 Interconnecting printed wiring board	90	44
040202 Test Adapter MX 8618/APS-94D 4A2	90	45
04020201 Fast switch driver 4A2A1	90	46
04020202 Audio oscillator 4A2A2	96	47
04020203 Interconnecting printed wiring board	96	48
040203 Test Adapter MX 8629/APS-94D 4A3	96	49
04020301 channel multiplexer 4A3A1	99	42
04020302 Buffer driver 4A3A2	99	43
04020303 Interconnecting printed wiring board	99	50
040204 Test Adapter MX 8617/APS-94D 4A4	99	51
04020401 Bite counter checker 4A4A1	99	52
04020402 Bite sequencer negative 4A4A2	99	53
04020403 Level translator 4A4A3	105	54
04020404 Interconnecting printed wiring board	105	55
040205 Test Adapter MX-8618/APS-94D 4A5	105	56
04020501 Video signal generator 4A5A1	105	57
04020502 Analog multiplexer 4A5A2	112	58
04020503 Video generator 4A5A3	112	59
04020504 Interconnecting printed wiring board	114	60
040206 Test Adapter MX-8619/APS-94D 4A6	114	61
04020601 Test signal generator 4A6A1	114	62
04020602 Digital multiplexer 4A6A2	118	63
04020603 Interconnecting printed wiring board	118	64
040207 Test Adapter MX-8620/APS-94D 4A7	118	65
04020701 Random number generator 4A7A1	118	66
04020702 Interconnecting printed wiring board	123	67
040208 Test Adapter MX-8621/APS 94D 4A8	123	68
04020801 32 channel multiplexer 4A8A1 4A8A2	123	42
04020802 Module 4A8A3	123	69
04020803 Interconnecting printed wiring board	127	70
040209 Test Adapter MX 8622 APS 94D 4A9	127	71
04020901 32 channel multiplexer 4A9A1	127	42
04020902 Buffer driver 4A9A2	127	43
04020903 Interconnecting printed wiring board	127	72
040210 Test Adapter MX 8623/APS-94D 4A10	127	73
04021001 32 channel multiplexer 4A10A1	133	42
04021002 Buffer driver 4A10A2	133	43
04021003 Interface driver 4A10A3	133	74
04021004 Interconnecting printed wiring board	133	75
040211 Test Adapter MX 8624/APS-94D 4A11	133	76
04021101 Bit adder 1A11A1	133	77
04021102 Analog/digital multiplexer 4A11A2	137	78
04021103 Interconnecting printed wiring board	140	79
040212 Test Adapter MX 8625/APS-94D 4A12	140	80
04021201 Ladder sequencer storage 4A12A1	140	81
04021202 Bite sequencer 4A12A2	140	82
04021203 Interconnecting printed wiring board	140	83
040213 Test Adapter MX 8626/APS-94D 4A13	145	84
04021 Buffer driver 4A13A1	145	43
04021302 Interconnecting printed wiring board	145	85
040214 Test Adapter MX 8627/APS-94D 4A14	145	86
04021401 Bite synchronizer 4A14A1	145	87
04021402 Mode control 4A14A2	145	88
04021403 Digital multiplexer 4A14A3	152	89
04021404 Interconnecting printed wiring board	152	90

		Page	Illustration Figure
	Repair Parts list-Continued		
	040215 Test Adapter MX-8628/APS-94D 4A15	152	91
	04021501 32 channel multiplexer 4A15A1	152	42
	040201502 Buffer inverter 4A15A2	152	92
	04021503 Interconnecting printed wiring board	156	93
SECTION	III Special Tools List	159	
<b>Group</b>	<b>05</b> Special Tools	159	94
SECTION	IV Federal <b>stock</b> number and part number index	161	

SECTION I  
INTRODUCTION

1. Scope

This manual lists repair parts: special tools; and other support equipment required for performance of organizational, direct support, general support and depot maintenance of the Test Set Group, Processor, Radar, OQ/-61/APS-94D

2. General

This Repair Parts and Special Tools List is divided into the following sections

*a Section II-Repair Parts List* A list of repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending numerical sequence, with the parts in each group listed in figure and item number sequence.

*b Section III- Special Tools List* A list of special tools and support equipment authorized for the performance of maintenance at the general support level.

*c Section IV-Federal Stock Number and Part Number Index* A list, in ascending numerical sequence, of all Federal Stock Numbers appearing in the listings, followed by a list, in alphameric sequence of all part numbers appearing in the listings. Federal stock number and part numbers are cross-referenced to each Illustration figure and item number appearance.

3. Explanation of Columns

The following provides an explanation of columns found in the tabular listings:

*a Illustration.* This column is divided as follows:

(1) *Figure number* Indicates the figure number of the Illustration in which the item is shown.

(2) *Item number* The number used to identify each item called out in the illustration

*b. Source, Maintenance, and Recoverability Codes (SMR).*

(1) *Source code* Source codes are assigned to support items to indicate the manner of acquiring Support Items for maintenance, repair, or overhaul of end items Source codes are entered in the first and second positions of the Uniform SMR Code format as follows

<i>Code</i>	<i>Definition</i>
PA	Item procured <b>and</b> stocked for anticipated or known usage
PD	Support item excluding support equipment <b>procured for initial issue or outfitting and</b>

<i>Code</i>	<i>Definition</i>
	stocked only for subsequent or additional initial issues or outfittings Not subject to automatic replenishment
PE	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities
A0	Item to be assembled at organizational level
MD	Item to be manufactured or fabricated at the depot maintenance level
AH	Item to be assembled at general support maintenance level
XB	Item is not procured or stocked If not available through salvage, requisition

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA, XD, and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code as follows.

(a ) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

<i>Code</i>	<i>Application/Explanation</i>
0	Support Item is removed, replaced, used at the organizational level
H	Support Item is removed replaced, and used at the general support level
D	Support Items that are removed, replaced, used at depot only

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). Thns position will contain one of the following maintenance codes:

<i>Code</i>	<i>Application Explanation</i>
H	The lowest maintenance level <b>capable of complete repair of the support item is the general support level</b>
D	The lowest maintenance level <b>capable of complete repair of the support item is the depot level performed by depot</b>
Z	<b>Nonreparable No repair is authorized</b>