

TECHNICAL MANUAL

**ORGANIZATIONAL, DIRECT SUPPORT AND GENERAL SUPPORT
MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)**

MAINTENANCE ACCESSORIES KIT

M K - 1 1 9 2 / A R M

(NSN 6625-00-179-1699)

H E A D Q U A R T E R S , D E P A R T M E N T O F T H E A R M Y

August 1975

Technical Manual

No. 11-6625-2405-24P

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, DC 29 August 1975

**ORGANIZATIONAL, DIRECT SUPPORT AND GENERAL SUPPORT
MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)**

**MAINTENANCE ACCESSORIES KIT MK-1192/ARM
(NSN 6625-00-179-1699)**

Current as of May 1975

Table of Contents

	Page	Illus Figure
Section	I. Introduction	1
	II. Repair Parts List	5
Group	00 Maintenance Accessories Kit MK-1192/ARM	5
	01 Ancillary items	5
	02 Adapter, Breakout MX-8497/ARM	5
	03 Cable Assembly CX-12172/ARM	8
	04 Adapter, Breakout MX-8498/ARM	8
	05 Cable Assembly CX-12173/ARM	10
	06 Adapter, Breakout MX-8498/ARM	10
	07 Cable Assembly CX-12174/ARM	12
	08 Termination Box Assembly MX-8500/ARM	12
	09 Bulk material	14
	III. Special tools list (Not applicable)	
	IV. Federal stock number, Part No. Index	

* This manual supersedes TM 11-6625-2405-25P, 23 June 1969, including all changes.

**SECTION I
INTRODUCTION**

1. Scope

This manual lists repair parts and special tools required for performance of organizational, direct support, and general support maintenance of the MK-1192/ARM.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II-Repair Parts List. A list of repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending numerical sequence, with the parts in each group listed in figure and item number sequence. Bulk materials are listed in FSN sequence.

b. Section III-Special Tools List. Not applicable.

c. Section IV-Federal Stock Number and Part Number Index. A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. Federal stock number and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

The following provides an explanation of columns found in the tabular listings:

a. Illustration. This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration in which the item is shown.

(2) *Item number.* The number used to identify each item called out in the illustration.

b. Source, Maintenance, and Recoverability Codes (SMR).

(1) *Source code.* Source codes are assigned to support items to indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

<i>Code</i>	<i>Definition</i>
PA	Item procured and stocked for anticipated or known usage.
PB	Item procured and stocked for insurance purpose because essentiality dictates that a minimum quantity be available in the supply systems.
XA	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA, XD, and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

<i>Code</i>	<i>Application/explanation</i>
O	Support item is removed, replaced, used at the organizational level.
F	Support item is removed, replaced, used at the direct support level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e.,