

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

---

**ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT  
MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS  
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)**

**FOR**

**TEST SET, RADIO FREQUENCY POWER AN/URM-182  
(NSN 6625-00-148-9371)**

---

Headquarters, Department of the Army, Washington, D.C.  
17 October 1977

---

*Current as of 11 July 1977*

**REPORTING OF ERRORS**

You can help improve this manual by calling attention to errors and by recommending improvements and stating your reasons for the recommendation. Your letter or DA Form 2028 (Recommended Changes to Publication and Blank Forms) should be mailed direct to Commander, US Army Electronics Command. ATTN: DRSEL-MA-Q Fort Monmouth New Jersey 07703. A reply will be furnished direct to you.

**Table of Contents**

		Page	Figure	Illus
SECTION I.	Introduction .....	1		
II.	Repair parts list .....	5		
Group 00	Test Set, Radio Frequency Power AN/URM- 182 .....	5		1
Section III.	Special tools list (Not applicable)			
IV.	National stock number and part number index .....	6		

---

\* \* This manual supersedes\* - manual supersedes so much of TM 11-6625-2718-14&P, 30 June 1975, as pertains to repair parts and special tools list.

# SECTION I INTRODUCTION

---

## 1. Scope

This manual lists spares and repair parts; special tools: special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational, direct support, and general support maintenance of the AN/URM-182. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

## 2. General

This Repair Part and Special Tools List is divided into the following sections:

*a. Section II. Repair Parts List.* A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

*b. Section III. Special Tools List.* Not applicable.

*c. Section IV. National Stock number and Part Number Index.* A list, in National item identification number (NSN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphanumeric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

## 3. Explanation of Columns

*a. Illustration.* This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* The number used to identify item called out in the illustration.

*b. Source, Maintenance, and Recoverability (SMR) Codes.*

(1) *Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

<i>Code</i>	<i>Definition</i>
-------------	-------------------

PA - Item procured and stocked for anticipated or known usage.

XD - A support item that is not stocked. When

*Code*

*Definition*

required, item will be procured through normal supply channels.

### NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

*Code*

*Application/Explanation*

O - Support item is removed, replaced, used at the organizational level.

F - Support item is removed, replaced, used at the direct support level.

H - Support item is removed, replaced, used at the general support level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

*Code*

*Application/Explanation*

H - The lowest maintenance level capable of complete repair of the support item is the general support level.

Z - Nonreparable No repair is authorized.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

*Recoverability*

*codes*

*Definition*

Z - Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.

H - Repairable item. When uneconomically repairable, condemn and dispose at the general support level.