

TECHNICAL MANUAL
ORGANIZATIONAL, DIRECT SUPPORT,
AND GENERAL SUPPORT
MAINTENANCE REPAIR PARTS AND
SPECIAL TOOLS LISTS
(INCLUDING DEPOT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS)
FOR
TESTS SETS,
RADAR AN/APM-246
(NSN 6625-00-943-2059)
AND AN/APM-247
(NSN 6625-00-908-9577)

HEADQUARTERS, DEPARTMENT OF THE ARMY

SEPTEMBER 1976

**ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT
 MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS
 (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)**

**FOR
 TEST SETS, RADAR AN / APM-246 (NSN 6625-00-943-2059)**

AND AN / APM-247 (NSN 6625-00-908-9577)

Current as of 29 April 1976

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 2028-2 (Test) located in the back of the manual. Simply tear out the self-addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Form 2028-2 (Test) in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Electronics Command, ATTN: DRSEL-MA-Q, Fort Monmouth, New Jersey 07703.

In either case, a reply will be furnished direct to you.

Table of Contents

		Page	Illus Figure
Section	I. Introduction.....	1	
	II. Repair parts list 4AN/AMP-246)	5	
Group	00 Test Set, Radar AN/APM-246	5	1
	01 Test Set, Radar, Preflight TS-2154()/APM-246	7	2-4
	02 Waveguide Assembly CG-3098/APM-246 (See next higher assembly)		
	03 Cable Assemblies for AN/APM-246	15	
	0301 Cable Assembly, Special Purpose, Electrical CX-10030()/APM-246	15	5
	0302 Cable Assembly, Special Purpose, Electrical CX-10031()/APM-246	15	5
	0303 Cable Assembly, Special Purpose, Electrical CX-10032()/APM-246	15	5
	0304 Cable Assembly, Special Purpose, Electrical CX-10033()/APM-246	15	5
	0305 Cable Assembly, Special Purpose, Electrical CX-10034()/APM-246	15	5
	0306 Cable Assembly, Special Purpose, Electrical CX-10035()/APM-246	15	5
	04 Bulk material	16	
Section	III Special tools list (AN/APM-246) (Not applicable)		
	IV National stock number and part number index (AN/APM-246)	18	
	V Repair parts list (AN/APM-247)	23	
Group	00 Test Set, Radar AN/APM-247	23	6
	01 Test Set, Radar TS-2081()/APM-247	27	7-12
	02 Cable Assemblies for AN/APM-247	51	
	0201 Cable Assembly, Power, Electrical CX-10029/APM-247	51	13
	0202 Cable Assembly, Special Purpose, Electrical CX-11555/APM-247	51	13
	0203 Cable Assembly, Special Purpose, Electrical CX-10242/APM-247	51	13
	0204 Cable Assembly, Radio Frequency CG-1464/U.....	51	13

***This manual supersedes so much of TM 11-6625-664-12, 28 June 1966, including all changes, and TM 11-6625-664-45, 10 May 1967, as pertains to repair parts and special tools lists.**

		Page	Illus Figure
Section	03 Bulk material	52	
	VI Special tools list (AN/APM-247) (Not applicable)		
	VII National stock number and part number index (AN/APM-247)	54	

SECTION I

INTRODUCTION

1. Scope

This manual lists repair parts required for performance of organizational and general support maintenance of the AN/APM-246 and AN/APM-247.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. *Section II. Repair Parts List (AN/APM-246).* A list of repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending numerical sequence, with the parts in each group listed in figure and item number sequence. Bulk materials are listed in NSN sequence.

b. *Section III Special Tools List (AN/APM-246).* Not applicable.

c. *Section IV National Stock Number and Part Number Index (AN/APM-246).* A list, in ascending numerical sequence, of all National stock numbers appearing in the listings, followed by a list, in alphanumeric sequence, of all part numbers appearing in the listings. National stock number and part numbers are cross-referenced to each illustration figure and item number appearance.

d. *Section V Repair Parts List (AN/APM-247).* A list of repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending numerical sequence, with the parts in each group listed in figure and item number sequence. Bulk materials are listed in NSN sequence.

e. *Section VI. Special Tools List (AN/APM-247).* Not applicable.

f. *Section VII. National Stock Number and Part Number Index (AN/APM-247).* A list, in ascending numerical sequence, of all National stock numbers appearing in the listings, followed by a list, in alphanumeric sequence, of all part numbers appearing in the listings. National stock number and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

The following provides an explanation of columns found in the tabular listings:

a. *Illustration.* This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration in which the item is shown.

(2) *Item number.* The number used to identify each item called out in the illustration.

B Source, Maintenance, and Recoverability Codes (SMR).

(1) *Source code.* Source codes are assigned to support items to indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

<i>Code</i>	<i>Definition</i>
PA--	Item procured and stocked for anticipated or known usage.
PD--	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
XA--	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XD--	A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA, XD, and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance: