
TECHNICAL MANUAL

GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS

(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)

FOR

AN/ARM-92 AND AN/ARM-92A

HEADQUARTERS, DEPARTMENT OF THE ARMY

APRIL 1973

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

General Support Maintenance Repair Parts and Special Tools List
 (Includes Depot Maintenance Repair Parts and Special Tools)

FOR
 TEST SETS, RADIO
 AN/ARM-92 AND AN/ARM-92A

Headquarters, Department of the Army, Washington, D.C.

15 April 1973

Current as of 15 November 1972

	Paragraph	Page
SECTION I. INTRODUCTION		1
Scope	1	1
General	2	1
Explanation of columns	3	1
Special information	4	2
How to locate repair parts.	5	2
Federal supply code	6	3
Recommendations for maintenance publication improvements	7	4
II. REPAIR PARTS FOR DS, GS, AND DEPOT MAINTENANCE		5
III. INDEX - FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS-REFERENCE TO FIGURE AND REFERENCE DESIGNATION		21
IV. INDEX - REFERENCE DESIGNATION CROSS-REFERENCE TO PAGE NUMBER		29

This manual supersedes Appendix B (DS, GS, and Depot Repair Parts) of TM 11-6625-820-45, 22 September 1966.

SECTION I

INTRODUCTION

1. Scope.

This manual lists repair parts and special tools required for the performance of direct support, general support, and depot level maintenance of the AN/ARM-92 and AN/ARM-92A.

2. General.

This Repair Parts and Special Tools List is divided into the following sections:

a. Repair Parts - Section II. A list of repair parts authorized for the performance of maintenance at the direct support, general support, and depot level.

b. Federal Stock Number and Reference Number Index - Section III. A list of Federal stock numbers in ascending numerical sequence followed by a list of reference numbers (Manufacture P/N) in ascending alpha-numeric sequence, cross-referenced to the illustration figure number and reference designation.

c. Reference Designation Cross-Reference to Page Number Index - Section IV. A list of reference designation numbers in alpha-numeric sequence, cross-referenced to page number of the Repair Parts List.

3. Explanation of columns.

The following provides an explanation of columns in the tabular lists in Section II.

a. Source, Maintenance and Recoverability Codes (SMR), Column 1.

(1) Source code indicates the selection status and source for the listed item. Source codes are:

<u>Code</u>	<u>Explanation</u>
<u>P</u>	- applies to repair parts that are stocked in or supplied from the GSA/DSA, or Army supply system, and authorized for use at indicated maintenance categories.
<u>M</u>	- applies to repair parts that are not procured or stocked, but are to be manufactured at indicated maintenance categories.
<u>A</u>	applies to assemblies that are not procured or stocked as such, but are made up of two or more units, each of which carry individual stock numbers and descriptions, and are procured and stocked and can be assembled by units at indicated maintenance categories.
<u>X</u>	- applies to parts and assemblies that are not procured or stocked; the mortality of which

normally is below that of the applicable end item; and the failure of which should result in retirement of the end item from the supply system.

XI - applies to repair parts which are not procured or stocked, the requirement for which will be supplied by the use of the next higher assembly or component.

X2 - applies to repair parts which are not stocked. The indicated maintenance category requiring such repair parts will attempt to obtain them through cannibalization; if not obtainable through cannibalization, such repair parts will be requisitioned with supporting justification through normal supply channels.

C - applies to repair parts authorized for local procurement. If not obtainable from local procurement, such repair parts will be requisitioned through normal supply channels with a supporting statement of nonavailability from local procurement.

G - applies to major assemblies that are procured with PEMA funds for initial issue only to be used as exchange assemblies at DSU and GSU level. These assemblies will not be stocked above DSU and GSU level or returned to depot supply level.

(2) Maintenance code indicates the lowest category of maintenance authorized to install the listed item. The maintenance level code is:

<u>Code</u>	<u>Explanation</u>
<u>C</u>	- Crew or operator maintenance
<u>O</u>	- Organizational maintenance
<u>F</u>	- Direct Support maintenance
<u>H</u>	- General Support maintenance
<u>D</u>	- Depot maintenance

(3) Recoverability code indicates whether unserviceable items should be returned for recovery on salvage. Items not coded are expendable. Recoverability codes are: