

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND
SPECIAL TOOLS LISTS
FOR
GENERATOR, SIGNAL SG-321 B/U
(NSN 6625-00-935-6924)

Headquarters, Department of the Army, Washington, DC
22 November 1976

Current as of 7 September 1976

REPORTING OF ERRORS

You can help improve this manual by calling attention to errors and by recommending improvements and stating your reasons for the recommendations. Your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms) should be mailed direct to Commander, US Army Electronics Command, ATTN: DRSEL-MA-Q, Fort Monmouth, New Jersey 07703. A reply will be furnished direct to you.

Table of Contents

| | | Page | Illus Figure |
|---------|--|-------------|-------------------------|
| SECTION | I. Introduction..... | 1 | |
| | II. Repair parts list..... | 5 | |
| Group | 00 Generator, Signal SG-321B/U..... | 5 | 1,2 |
| SECTION | III. Special tools list (Not applicable) | | |
| | IV. National stock number and part number index (Not applicable) | | |

*This manual supersedes so much of TM 11462-822-12, 5 December 19i8, as pertains to repair parts and special tools list.

**SECTION I
INTRODUCTION**

1. Scope :

This manual lists repair parts and special tools required for performance : organizational maintenance of the SG-321B/U.

2. General.

This Repair Parts and Special Tools List is divided into the following sections:

a. *Section II. Repair Parts List.* A list of repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized part. Parts lists are composed of functional groups in ascending numerical sequence, with the parts in: each group listed in figure and item number sequence.

b. *Section III. Special Tools List.* Not applicable.

c. *Section IV. National Stock Number and Part Number Index.* Not applicable.

3. Explanation of Columns

The following provides an explanation of columns found in the tabular listings:

a. *Illustration.* This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration in which the item is shown.

(2) *Item number.* The number used to identify each item called out in the illustration.

b. *Source, Maintenance, and Recoverability Codes (SMR).*

(1) *Source code.* Source codes are assigned to support items to indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

| | |
|-------------|-------------------|
| <i>Code</i> | <i>Definition</i> |
|-------------|-------------------|

PA--Item procured and stocked for anticipated or known usage.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA, XD, and aircraft support items as restricted by AR 70042.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

| | |
|-------------|--------------------------------|
| <i>Code</i> | <i>Application/Explanation</i> |
|-------------|--------------------------------|

O--Support item is removed, replaced, used at the organizational level.

(b) The maintenance code entered in the fourth position indicates whether the-item is to be repaired and identifies the lowest maintenance level with the capability to perform .complete repair (i.e., all authorized maintenance functions) This position will contain one of the following maintenance codes:

| | |
|-------------|--------------------------------|
| <i>Code</i> | <i>Application/Explanation</i> |
|-------------|--------------------------------|

Z--Nonreparable. No repair is authorized.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

| | |
|-----------------------------|-------------------|
| <i>Recoverability codes</i> | <i>Definition</i> |
|-----------------------------|-------------------|

Z--Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.

c. *National Stock Number.* Indicates the National stock number assigned to the item and will be used for requisitioning purposes.

d. *Part Number.* Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications standards, and inspection requirements, to identify an item or range of items.

NOTE

When a stock numbered item is requisitioned, the repair part received may have a different part number than the part being replaced.

e. *Federal Supply Code for Manufacturer (FSCM).* The FSCM is a 5digit numeric code listed in SB 70842 which is used to identify the manufacturer, distributor, or Government agency, etc.

f. *Description.* Indicates the Federal item name and, if required, a minimum description to identify the item.

g. *Unit of Measure (U/M).* Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc.). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be' requisitioned.

h. *Quantity Incorporated in Unit.* Indicates the