

TECHNICAL MANUAL

ORGANIZATIONAL, DIRECT SUPPORT AND  
GENERAL SUPPORT MAINTENANCE  
REPAIR PARTS AND SPECIAL TOOLS LIST  
(INCLUDING DEPOT MAINTENANCE REPAIR  
PARTS AND SPECIAL TOOLS)

FOR

SIGNAL GENERATOR SG-1174/U

(NSN 6625-01075-8479)

**ORGANIZATIONAL, DIRECT SUPPORT AND  
 GENERAL SUPPORT MAINTENANCE  
 REPAIR PARTS AND SPECIAL TOOLS LIST  
 (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND  
 SPECIAL TOOLS)  
 FOR  
 SIGNAL GENERATOR SG-1174/U  
 (NSN 6625-01-075-8479)**

Current as of 25 January 1982

**REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS**

You can improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to Commander, US Army Communications-Electronics Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, NJ 07703.

In either case, a reply will be furnished direct to you.

**Table of Contents**

SECTION		Page	Illus Figure
	I. Introduction . . . . .	1	
	II. Repair Parts List . . . . .	5	
	00 Generator, Signal, SG-1174/U . . . . .	5	1
	Generator, Signal, SG-1174/U, Major Components . . . . .	7	2
	01 Dust Cover Assembly (A9) . . . . .	9	3
	02 Main Frame . . . . .	15	4
	0201 Cable Assembly . . . . .	19	5
	03 1,000 Volt Power Supply Assembly . . . . .	23	6
	04 Keyer Power Supply Assembly A2 . . . . .	27	7
	05 1,600 Volt Power Supply Assembly A . . . . .	31	8
	06 Low Voltage Power Supply Assembly A . . . . .	35	9
	07 Modulator Circuit Board Assembly A6 . . . . .	39	10
	08 Keyer and Tracker Assembly A7 . . . . .	45	11
	09 RF Tuning Unit Assembly All . . . . .	49	12
	10 Front Panel Assembly A12 . . . . .	51	13
SECTION	III. Special Tools List (Not applicable)		
	IV. National Stock Number and Part Number Index . . . . .	52	

# SECTION I

## INTRODUCTION

---

### 1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational, direct support, and general support maintenance of the SG-1174/U. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

### 2. General

This Repair Parts and Special Tools List is divided into the following sections:

*a. Section II. Repair Parts List.* A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

*b. Section III. Special Tools List.* Not applicable.

*c. Section IV. National Stock Number and Part Number Index.* A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

### 3. Explanation of Columns

*a. Illustration.* This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* The number used to identify item called out in the illustration.

*b. Source, Maintenance, and Recoverability (SMR) Codes.*

(1) *Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SRM Code format as follows:

<i>Code</i>	<i>Definition</i>
-------------	-------------------

PA -	Item procured and stocked for anticipated or known usage.
------	---

<i>Code</i>	<i>Definition</i>
-------------	-------------------

PD -	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
------	--

AH -	Item to be assembled at general support maintenance level.
------	--

XA -	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
------	---

XD -	A support item that is not stocked. When required, item will be procured through normal supply channels.
------	--

#### NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

<i>Code</i>	<i>Application/Explanation</i>
-------------	--------------------------------

O -	Support item is removed, replaced, used at the organizational level.
-----	--

H -	Support item is removed, replaced, used at the general support level.
-----	---

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

<i>Code</i>	<i>Application/Explanation</i>
-------------	--------------------------------

H -	The lowest maintenance level capable of complete repair of the support item is the general support level.
-----	---