

TM 11-6625-2975-24P

TECHNICAL MANUAL

**ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL
SUPPORT MAINTENANCE REPAIR PARTS AND
SPECIAL TOOLS LISTS**

**FOR
TEST SET, RECEIVER AN/ARM-180
(NSN 6625-01-041-4161)**

HEADQUARTERS, DEPARTMENT OF THE ARMY

19 JULY 1984

Technical Manual }
No. 11-6625-2975-24P }

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, DC, 19 July 1984

**ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LIST**

**FOR
TEST SET, RECEIVER
AN/ARM-180 (NSN 6625-01-041-4161)**

Current as of 3 April 1984

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms) or DA Form 2028-2 located in the back of this manual direct to: Commander, US Army Communications-Electronics Command and Fort Monmouth, ATTN: DRSEL-ME-MP, Fort Monmouth, New Jersey 07703-5007. A reply will be furnished direct to you.

TABLE OF CONTENTS

| | Page | Illus Figure |
|---|------|-----------------|
| Section I. Introduction | 1 | |
| II. Repair Parts List | 5 | |
| Group 00 Test Set VOR/ILS AN/ARM-180 | 5 | 1 |
| 01 Front Panel Assembly A1 | 9 | 2 |
| 02 Controller Audio Assembly A2 (No parts authorized) | | |
| 03 RF Modulator Assembly A3 (No parts authorized) | | |
| 04 Synthesizer Assembly A4 (No parts authorized) | | |
| 05 Power Supply Assembly A5 (No parts authorized) | | |
| Section III. Special Tools List | 13 | 3 |
| IV. National Stock Number and Part Number Index | 14 | |

*This manual supersedes so much of TM 11-6625-2975-14&P, 30 December 1980, as pertains to Parts List, Section VI.

SECTION I

INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational, direct support, and general support maintenance of the AN/ARM-180. It authorizes requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools Lists. A list of special tools, special TMDE, and other special support equipment authorized for the performance of maintenance.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) *Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

| <i>Code</i> | <i>Definition</i> |
|-------------|---|
| PA | —Item procured and stocked for anticipated or known usage. |
| PE | —Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities. |
| XB | —Item is not procured or stocked. If not available through salvage, requisition. |

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 750-1.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

| <i>Code</i> | <i>Application/Explanation</i> |
|-------------|---|
| O | — Support item is removed, replaced, used at the organizational level. |
| H | — Support item is removed, replaced, used at the general support level. |

(b) The maintenance code entered in the fourth position indicates whether the item is to be