TECHNICAL MANUAL

ORGANIZATIONAL DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)

FOR

CALIBRATOR, AC 0-1804/USM-410(V) (NSN 6625-01-100-6196)

HEADQUARTERS, DEPARTMENT OF THE ARMY

24 OCTOBER 1983

TECHNICAL MANUAL .

HEADQUARTERS DEPARTMENT OF THE ARMY Washington, DC, 24 October 1983

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT

MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)

FOR

CALIBRATOR, AC 0-1804/USM-410(V)

(NSN 6625-01-100-6196)

Current as of 5 July 1983

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in back of this manual direct to: Commander, US Army Communications-Electronics Command and Fort Monmouth, ATTN.: DRSEL-ME-MP, Fort Monmouth, NJ 07703.

In either case, a reply will be furnished direct to you.

i

Table of Contents

			Page	lllus. Figure
SECTION	I.	Introduction	. 1	-
	II.	Repair Parts List		
GROUP	00	Calibrator, AC 0-1804/USM-410(V)		1
	01	Mother Board Assembly A2		2
	02	Switchboard A3		3
	03	Power Supply Assembly A5		4
		0301 Power Supply Printed Circuit Board		
		A5A1	. 19	5
		0302 Power Supply Regulator A5A2	. 21	6
		0303 Transformer Printed Circuit Board		
		Subassembly A5A3	. 25	7
	04	Attenuator Assembly A6	. 27	8
	05	Power Amplifier Assembly A7	. 31	9
	06	AC-DC Converter Assembly A8	. 37	10
	07	Oscillator Control, PCB Assembly A9		11
	08	Oscillator, PCB Assembly A10.	. 47	12
	09	Remote Control Unit A11		13
	10	Reference Assembly A12	. 55	14
SECTION	III.	Special Tools List (Not applicable)		
	IV.	National Stock Number and Part Number Index	. 58	

ii

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational, direct support, and general support maintenance of the 0-1804/USM-410(V). It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes

2. General

This Repair Parts and Special Tools List is divided into the following sections:

Section II. Repair Parts List. A list of а. spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups numeric sequence, with the parts in each group listed in figure and item number sequence. Bulk materials are listed in NSN sequence.

Special Tools List. b. Section III. Not applicable.

Section IV. National Stock Number and C. Pan Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing m the listings, followed by a list, in alphanumeric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

Explanation of Columns 3.

This column is divided as Illustration. a. follows.

(1) Figure number. Indicates the figure number of the illustration on which the item is shown.

(2) Item number. The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) Source code. Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows.

Code Definition

- Item procured and stocked for anticipated or PA _ known usage
- XA Item is not procured or stocked because the _ requirements for the item will result in the replacement of the next higher assembly.
- Item is not procured or stocked. XB If not available through salvage, requisition.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 750-1.

(2) Maintenance code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR code as follows.

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance.

Code Application/Explanation

- 0 Support item is removed, replaced, used at the organizational level.
- Н _ Support item is removed, replaced, used at the general support level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Application/Explanation Code

- Н The lowest maintenance level capable of complete repair of the support item is the general support level. Ζ
 - Nonreparable. No repair is authorized. _

(3) Recoverability code. Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows :

Recoverability

- Definition Code
- Ζ Nonreparable item. When unserviceable, condemn and dispose at the level indicated min position 3.
- Н Reparable item When uneconomically reparable, condemn and dispose at the general support level.

National Stock Number. Indicates the National С. stock number assigned to the item and will be used for requisitioning purposes.