TECHNICAL MANUAL

UNIT, INTERMEDIATE DIRECT SUPPORT AND INTERMEDIATE GENERAL SUPPORT MAINTENANCE

REPAIR PARTS AND SPECIAL TOOLS LIST

FOR

LAUNDRY UNIT, TRAILER MOUNTED

MODEL M85

NSN 3510-01-222-9301

*This manual supersedes TM 10-3510-209-24P, 10 August 1988

Approved for public release; distribution is unlimited.

HEADQUARTERS, DEPARTMENT OF THE ARMY
31 MAY 1989

TECHNICAL MANUAL
NO. 10-3510-209-24P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 31 MAY 1989

UNIT, INTERMEDIATE DIRECT SUPPORT, AND INTERMEDIATE GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST FOR LAUNDRY UNIT, TRAILER MOUNTED MODEL M85 NSN 3510-01-222-9301

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, US Army Aviation and Troop Command, ATTN: AMSAT-I-MP, 4300 Goodfellow Blvd., St. Louis, MO 63120-1798. A reply will be furnished directly to you.

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

TABLE OF CONTENTS

		Page	Illus/ Figure
SECTION I	INTRODUCTION	1	
SECTION II	REPAIR PARTS LIST	1-1	
Group 01	Tarp Cover Assembly	1-1	1
Group 02	Tarp Frame Assembly	2-1	2
Group 03	Sound Deadening Panel Assemblies	3-1	3
Group 04	Platform Assembly	4-1	4
Group 05	Washer Assembly		
	Washer Soap Chute	5-1	5
	Washer Rear Assembly	6-1	6
	Washer Float Level Assembly	7-1	7
	Washer Drain Assembly	8-1	8
	Washer Door Assembly	9-1	9
	Washer Cylinder Assembly	10-1	10
	Washer Shell and Base Assembly	11-1	11
	Air Tank	12-1	12
	Miltrol Controller	13-1	13
Group 06	Power Distribution Box Assembly	14-1	14
Group 07	Compressor Assembly	15-1	15
Group 08	Ground Rods Assembly	16-1	16
Group 09	Pre-Extract Bin Assembly	17-1	17

* This manual supersedes TM 10-3510-209-24P, 10 August 1988

TABLE OF CONTENTS (CONT)

		Page	Illus/ Figure
Group 11	Extractor Assembly	18-1	18
	Extractor Lid Assembly	19-1	19
	Extractor Curb and Basket Assembly	20-1	20
	Extractor Control Panel	21-1	21
	Starter Circuit	22-1	
	Extractor Brake Solenoid	23-1	23
	Extractor Trunnion Assembly	24-1	24
	Extractor Base	25-1	25
	Extractor Center Unit	26-1	26
Group 12	Water Heater Assembly		
	Water Heater Mounting	27-1	27
	Water Heater Power Transformer	28-1	28
	Water Heater Air Ball Valves	29-1	29
	Water Heater Thermostat	30-1	30
	Water Heater Swing Check and Drain Valves	31-1	31
	Water Heater Skid and Handle Assembly	32-1	32
	Water Heater Burner Head Assembly	33-1	33
	Water Heater Blower and Motor Assembly	34-1	34
	Water Heater Fuel Filter Assembly	35-1	35
	Water Heater Fuel Pump Assembly	36-1	36
	Water Heater Electric Control Assembly	37-1	37
	Drum Adapter Assembly	38-1	38
Group 13	Dryer Tumbler Assembly		
	Dryer Assembly Mounting	39-1	39
	Dryer Fuel Filter Assembly	40-1	40
	Dryer Fuel Pump Assembly	41-1	41
	Dryer Burner Assembly	42-1	42
	Dryer Motor and Blower Assembly	43-1	43
	Dryer Transformer and Solenoid	44-1	44
	Dryer Heat Exchanger	45-1	45
	Dryer Cylinder Assembly	46-1	46
	Dryer Trunnion Assembly	47-1	47
	Dryer Base and Control Assembly	48-1	48
	Dryer Gear Box and Motor Assemblies	49-1	49
	Exhaust Motor and Fan Assembly	50-1	50
	Dryer Bin Assembly	51-1	51
Group 14	Water Pump and Motor Assembly		
	Water Pump Tiedown Assemblies	52-1	52
	Water Pump and Motor Assembly	53-1	53
	Water Pump Strainer Assembly	54-1	54
Group 15	Water Hose Assemblies		
	Suction Strainer	55-1	55
	Hose Assemblies	56-1	56
Group 16	Exhaust Duct Assemblies	57-1	57
Group 17	Generator Tiedown	58-1	58
Group 18	Fire Extinguisher	59-1	59
Group 19	Tool Box	60-1	60
Group 20	M13 Decontamination Apparatus	61-1	61
Section III	SPECIAL TOOLS LIST (Not Applicable)		
Section IV.	CROSS-REFERENCE INDEXES	I-1	
	National stock number index	I-1	
	Part number index	I-3	
	Figure and Item number index	I-36	

UNIT, INTERMEDIATE DIRECT SUPPORT, AND INTERMEDIATE GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS

SECTION I. INTRODUCTION

1. SCOPE. This RPSTL lists and authorizes spares and repair parts; special ton's; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of unit, intermediate direct support, and intermediate general support maintenance of the laundry unit. It authorizes the requistioning, issue, and disposition of spares, repair parts and special tools as indicated by the source, maintenance and recoverability (SMR) codes.

2. GENERAL. In addition to this section, Introduction, this Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence. Bulk materials are listed in item name sequence. Repair parts kits are listed separately in their own functional group within Section II. Repair parts for repairable special tools are also listed in this section. Items listed are shown on the associated illustration(s)/figure(s).

b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in DESCRIPTION AND USABLE ON CODE column) for the performance of maintenance.

c. Section IV. Cross-references Indexes. A list, in National Item Identification Number (NIIN) sequence, of all National stock numbered items appearing in the listing, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance. The figure and item number index lists figure and item number in alphanumeric sequence and crossreferences NSN, FSCM and part number.

3. EXPLANATION OF COLUMNS (SECTIONS II AND III).

a. ITEM NO. (Column (1)). Indicates the number used to identify items called out in the illustration.

b. SMR Code (Column (2)). The Source, Maintenance, and Recoverability (SMR) code is a 5-position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instruction, as shown in the following breakout: