
TECHNICAL MANUAL

DIRECT SUPPORT AND GENERAL SUPPORT
MAINTENANCE REPAIR PARTS AND
SPECIAL TOOLS LIST

FOR

SIGNAL GENERATOR,
HEWLETT-PACKARD MODEL
8640BOPTION 001
(NSN 4931-00-545-2344)

HEADQUARTERS, DEPARTMENT OF THE ARMY

JUNE 1975

**Direct Support and General Support
Maintenance Repair Parts and Special Tools List
FOR
SIGNAL GENERATOR,
HEWLETT-PACKARD MODEL 8640BOPTION 001
(NSN 4931-00-545-2344)
Current as of 1 April 1975**

		Page
Section I.	Introduction	1-1
Section II.	Repair parts list	2-1
	FUNCTIONAL	
	GROUP	
	6614	
	GROUP TITLE	
	Signal Generator	
	MODEL	
	NO.	
	8640B	
	OPTION	
	001	
Section III.	NSN, reference number index	3-1

SECTION I. INTRODUCTION

1. Scope

This manual lists repair parts that are required for maintenance of Signal Generator, Hewlett-Packard Model 8640BOPTION 001 and is applicable to Army Area Calibration Teams (AACT's).

appearing in the repair parts list, followed by a list of all reference numbers in alpha-numeric sequence appearing in the list. The NSN's and reference numbers are cross-referenced to a figure number and item number in column 1.

NOTE

Throughout this manual, DS is used to indicate AACT.

NOTE

The figure and item number columns represent cross-reference numbers, since illustrations are not included in this manual

2. General

This manual is divided as follows:

- a. Section I. Introduction.
- b. Section II. Repair Parts List. A list, in alphabetical sequence, of repair parts authorized for the performance of maintenance at the AACT and AACL support level.
- c. Section III. National Stock Number and Reference Number Index. A list in ascending numerical sequence, of all National stock numbers (NSN's)

3. Explanation of Columns

Refer to section I of TM 94931-700-34P for explanation of columns (para 3), special information (para 4, except for subparagraph 40 which is not applicable to this manual), and abbreviations (para 6).

4. How to Locate Repair Parts

When NSN or reference number is unknown, use the repair parts listing and locate the item by description.

When National stock number or reference number is known, use the list of NSN's or the reference numbers and locate the cross-referenced figure and item number. Locate the cross-referenced figure and item number under column 1 of the repair parts list for the complete description of the repair part.

5. Reporting of Errors

The reporting of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be submitted on DA Form 2028, Recommended Changes to Publications, and forwarded direct to Commander, U. S. Army Missile Command, ATTN: AMSMI-MFM, Redstone Arsenal, AL 35809.