

TM9-1005-229-35

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

DS, GS, AND DEPOT MAINTENANCE MANUAL

INCLUDING REPAIR PARTS AND SPECIAL

TOOLS LISTS FOR

SUBMACHINE GUN, CALIBER .45, M3, W/E

(1005-672-1767)

SUBMACHINE GUN, CALIBER .45, M3A1, W/E

(1005-672-1771)

This copy is a reprint which includes current pages from Change 1.

HEADQUARTERS, DEPARTMENT OF THE ARMY

SEPTEMBER 1969

**DS, GS, AND DEPOT MAINTENANCE MANUAL
INCLUDING REPAIR PARTS AND SPECIAL TOOLS LISTS**

SUBMACHINE GUN, CALIBER .45, M3, W/E

(1005-672-1767)

SUBMACHINE GUN, CALIBER .45, M3A1, W/E

(1005-672-1771)

This manual is current as of 10 May 1969.

	Paragraph	Page
CHAPTER 1. INTRODUCTION		
Section I. General -----	1-1-1-2	3
II. Description and data -----	1-3	3
CHAPTER 2. DIRECT SUPPORT, GENERAL SUPPORT AND DEPOT MAINTENANCE INSTRUCTIONS		
SECTION I. Repair parts, special tools, and equipment -----	2-1	7
II. Troubleshooting -----	2-2	8
III. Preembarkation inspections of material in units alerted for overseas movement -----	2-3-2-5	9
IV. General maintenance -----	2-6-2-12	10, 11
V. Removal and installation -----	2-13	11
VI. Depot maintenance procedures -----	2-14	12
CHAPTER 3. REPAIR INSTRUCTIONS -----	3-1-3-5	13-17
CHAPTER 4. FINAL INSPECTION -----	4-14-4	19
APPENDIX A. REFERENCES -----	A-1-A-4	21
APPENDIX B. DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST		
Section I. Introduction -----	B-1-B-7	23-25
II. Repair Parts List		
Repair Parts For:		
Major groups, assemblies and components (figs B-1 and B-2) -----		26
Bolt and guide rod group (fig B-3) -----		27
Trigger housing group (figs B-4 and B-5) -----		23
Trigger and sear group (fig B-6) -----		29
Receiver assembly (figs. B-7 and B-8) -----		30
Flash hider assembly (fig B-9) -----		32
Oiler (fig B-10) -----		33
III. Special Tools List (fig B-10) -----		34
IV. Index—Federal Stock Number and Reference Number Cross-Reference to Figure and Item Number -----		36

* This manual supersedes TM 9-1005-229-35, 14 December 1964.

CHAPTER 1

INTRODUCTION

Section I. GENERAL

1-1. Scope

These instructions are in accordance with the maintenance allocation chart published for the use of direct support, general support, and depot maintenance personnel maintaining the Caliber .45, Submachine Guns, M3 and M3A1. They provide information on the maintenance of the equipment which is beyond the scope of the tools, equipment, personnel or supplies normally available to the operator and organizational maintenance.

1-2. Forms and Records

a. General. DA forms and procedures used for equipment maintenance will be only those prescribed in TM 38-750, Army Equipment Record Procedures.


b. Recommendation for Equipment Publication Improvements. Report of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reprints should be submitted on DA form 2028 (Recommended Changes to DA Publications) and forwarded direct to: Commanding General, Headquarters, U. S. Army Weapons Command, ATTN: AMSWE-SMM-P, Rock Island, Illinois 61201.

Section II. DESCRIPTION AND DATA

1-3. Description and Tabulated Data


Refer to TM 9-1005-229-12. For overall

views of the submachine gun refer to figures 1-1 and 1-2.



WE 63601

Figure 1-1. Caliber .45 Submachine Gun M3 w/Flash Hider Assembly, M9-right front view.



WE 63602

*Figure 1-2. Caliber .45 Submachine Gun M3A1 w/Flash Hider Assembly,
M9-right front view.*