

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

FIELD (FOURTH ECHELON) AND DEPOT MAINTENANCE REPAIR PARTS AND  
SPECIAL TOOL LISTS  
VOLTMETER, ELECTRONIC AN/URM-145

Headquarters, Department of the Army, Washington 25, D. C.

29 May 1963

SECTION I. INTRODUCTION	Paragraph	Page
Scope .....	1	1
Parts for maintenance .....	2	2
Electron tubes .....	3	2
Requisitioning information .....	4	2
References .....	5	2
Comments on parts lists .....	6	3
II. FUNCTIONAL PARTS LIST .....		4

---

SECTION I

INTRODUCTION

**1. Scope**

*a.* This manual lists the quantities of repair parts for fourth and fifth echelon field maintenance and is a basis for requisitioning authorized parts. It is also a guide for fifth echelon in establishing initial levels of spare parts.

*b.* Columns are as follows:

*(1) Source, maintenance, and recoverability code.* Source, maintenance, and recoverability codes indicate the technical service responsible for supply, the echelons where an item is stocked, echelons where an item is installed or repaired, and whether an item is repairable or salvageable. The

source code column is divided into four parts.

- (a) Column A.* This column indicates the technical service responsible for supply. AR 310-2 defines the basic numbers used to identify the technical services. If the part is supplied by the Signal Corps, the column is blank.
- (b) Column B.* Not used.
- (c) Column C.* This column indicates the lowest maintenance echelon authorize to install the part.  
"O" -Organizational maintenance (1st and 2d echelon).  
"H"-Field maintenance (4th echelon).  
"D"-Depot maintenance (5th echelon).