

# TM 11-6625-1614-15

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

---

ORGANIZATIONAL, DS, GS,  
AND DEPOT MAINTENANCE MANUAL

HEWLETT-PACKARD  
ELECTRONIC VOLTMETER  
MODEL 410C

This copy is a reprint which includes current  
pages from Change 1.

---

HEADQUARTERS, DEPARTMENT OF THE ARMY

AUGUST 1967

TECHNICAL MANUAL }  
No. 11-6625-1614-15 )

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, DC, 28 August 1967

ORGANIZATIONAL, DS, GS, AND DEPOT MAINTENANCE MANUAL

HEWLETT-PACKARD ELECTRONIC VOLTMETER  
MODEL 410C  
(NSN 6625-00-969-4105)


Section		Page
I	GENERAL INFORMATION -----	1-1
	1-A.1. Scope -----	1-1
	1-A.2. Index of Publications -----	1-1
	1-A.3. Maintenance Forms, Records, and Reports -----	1-1
	1-A.4. Reporting Errors and Recommending Improvements -----	1-2
	1-A.5. Reporting Equipment Improvement Recommendations (EIR)-----	1-2
	1-A.6. Administrative Storage -----	1-2
	1-1. Description -----	1-4
	1-4. Accessories Available -----	1-5
II	INSTALLATION -----	2-1
	2-1. Inspection -----	2-1
	2-3. Installation -----	2-1
	2-5. Rack Mounting -----	2-1
	2-9. Three - Conductor Power Cable -----	2-1
	2-12. Primary Power Requirements -----	2-1
	2-14. Repackaging for Shipment -----	2-2
III	OPERATION -----	3-1
	3-1. Introduction -----	3-1
	3-3. Adjustment of Mechanical Zero-----	3-1
	3-5. Front and Rear Panel Description -----	3-1
	3-7. Operating Procedures -----	3-1
	3-9. DC Voltage Measurements (Figure 3-2)-----	3-1
	3-11. DC Current Measurements (Figure 3-3)-----	3-1
	3-13. AC Voltage Measurements (Figure 3-4) -----	3-1
	3-15. Precautions When Measuring AC Voltage -----	3-1
	3-28. Negative Pulses -----	3-4
	3-31. Measuring Resistance (Figure 3-7) -----	3-4
	3-33. Measuring DC Nano-Ampere Current (Figure 3-8) -----	3-4
IV	THEORY OF OPERATION -----	4-1
	4-1. Overall Description -----	4-1
	4-4. Circuit Description -----	4-1
	4-5. Input Network -----	4-1
	4-16. Modulator - Demodulator -----	4-1
	4-23. The Feedback Network -----	4-2
	4-27. Power Supply -----	4-2
V	MAINTENANCE -----	5-1
	5-1. Introduction -----	5-1
	5-3. Test Equipment Required -----	5-1
	5-5. Performance Checks -----	5-1

Section		Page
5 - 7 .	Alternate Voltage Source -----	5- 1
5 - 9 .	Mechanical Meter Zero -----	5-1
5 - 1 0 .	DC Voltmeter OWration -----	5-1
5 - 1 3 .	DC Ammeter Operation -----	5-2
5 - 1 6 .	Ohmmeter Operation -----	5-4
5 - 1 7 .	Amplifier Operation -----	5-4
5 - 2 1 .	DC Amplifier Output Impedance Check -----	5-5
5 - 2 2 .	AC Voltmeter Operation -----	5-5
5 - 2 6 .	Adjustment and Calibration Prmedure -----	5-8
5 - 2 8 .	Chopper Frequency Adjust -----	5-8
5 - 2 9 .	Power Supply Adjustment -----	5-9
5 - 3 0 .	DC Zero Adjustment and Bias -----	5-10
5 - 3 1 .	DC Amplifier Output Adjust -----	5-10
5 - 3 3 .	Ohms Adjust (R3)-----	5-11
5 - 3 4 .	AC Zero Adjust -----	5-12
5 - 3 5 .	AC Full Scale Adjust (.5 V Range) -----	5-12
5 - 3 6 .	Troubleshooting Procedure -----	5-12
5 - 4 5 .	Servicing Etched Circuit Boards -----	5-14
5 - 4 8 .	Chopper, Assembly Installation -----	5-15


**LIST OF TABLES**

Number		Page
1-1.	Specifications -----	1-3
3-1.	Possible Error When Measuring Voltage of Complex Waveforms -----	3-3
5-1.	Recommended Test Equipment -----	5-0
5-2.	DCV Accuracy Test -----	5-2
5-3.	DCV Input Resistance Test -----	5-3
5-4.	DCA Accuracy Test -----	5-3
5-5.	Deleted	
5-6.	AC Accuracy Test -----	5-6
5-7.	Power Supply Test -----	5-9
5-8.	AC Full Scale Adjust -----	5-13
5-9.	Front Panel Troubleshooting Prmedure -----	5-16
5-10.	Troubleshooting Prwedure -----	5-17

**LIST OF ILLUSTRATIONS**

Number		Page
1-1.	The  Model 410C Electronic Voltmeter.-----	1-0
2-1.	The Combining Case -----	2-0
2-2.	Steps to Place Instrument in Combining Case-----	2-0
2-3.	Adaptor Frame Instrument Combination -----	2-1
2-4.	Two Half Modules in Rack Adaptor -----	2-2
3-1.	Front and Rear Panel Controls -----	3-2
3-2.	DC Voltage Measurements -----	3-5
3-3.	DC Current Measurements -----	3-6
3-4.	AD Voltage Measurements -----	3-7
3-5.	Maximum AC Voltage Chart for 11036A Probe -----	3-8
3-6.	Graph Used in Calculation of Pulse Voltage Readings -----	3-9
3-7.	Resistance Measurements -----	3-10
3-8.	DC Nano-Ampere Current Measurements -----	3-11
4-1.	Block Diagram, Model 410C -----	4-0
4-2.	Modulator - Demodulator Mechanical Analogy -----	4-0
4-3.	Simplified Schematic, DC Current Measurement -----	4-3

Number		<i>Page</i>
4-4.	Simplified Schematic, DC Voltage Measurements -----	4-4
4-5.	Simplified Schematic, Resistance Measurement -----	4-5
4-6.	Simplified Schematic, AC Voltage Measurement -----	4-6
5-1.	Alternate Voltage Source -----	5-1
5-2.	DC Ammeter Operation -----	5-3
5-3.	High Frequency Response Test -----	5-5
5-4.	Low Frequency Response Test -----	5-6
5-5.	Troubleshooting Tree -----	5-14
5-6.	A4 Chopper Assembly Installation -----	5-15
5-6.1	Chopper Frequency Adjust Setup -----	5-16.1
5-7.	Power Supply Measurements -----	5-17
5-8.	Power Supply Schematic -----	5-19
5-9.	Typical Amplifier Waveforms -----	5-20
5-10.	Amplifier Schematic -----	5-21
5-11.	Model 11036A AC Probe Exploded -----	5-22
5-12.	Model 11036A Probe Schematic -----	5-22
5-13.	RANGE and FUNCTION Switching (Pictorial) -----	5-23
5-14.	Input RANGE and FUNCTION Switching Schematic -----	5-24



**Figure 1-1. The Model 410C Electronic Voltmeter**

## SECTION I

### GENERAL INFORMATION

---

#### 1-A.1. Scope

*a.* This manual includes installation and operation instructions and covers operator's, organizational, direct support (DS), general support (GS), and depot maintenance. It describes Hewlett-Packard (Federal supply code 28480) Electronic Voltmeter Model 410C. This manual applies to equipments with serial numbers prefixed by 433 and serial number 532-03701 and higher. If the first three digits on your instrument are 550, refer to figure 5-10, note 14 for the change in equipments of this serial prefix.

*b.* A basic issue items list for this equipment is not included as part of this manual.

#### 1-A.2. Index of Publications

Refer to the latest issue of DA Pam 310-4 to determine whether there are new editions, changes, or additional publications pertaining to the equipment.

#### 1-A.3. Maintenance Forms, Records, and Reports

*a. Reports of Maintenance and Unsatisfactory Equipment.* Department of the Army forms and procedures used for equipment maintenance will be those prescribed by TM 38-750, The Army Maintenance Management System.

*b. Report of Item and Packaging Discrepancies.* Fill out and forward SF 364 (Report of Discrepancy (ROD)) as prescribed in AR 735-11-2/DLAR 4140.55/NAVMATINST 4355.73/AFR 400.54/MCO 4430.3E.

*c. Discrepancy in Shipment Report (DISREP) (SF361).* Fill out and forward Discrepancy in Shipment Report (DISREP) (SF 361) as prescribed in AR

55-38/NAVSUPINST 4610.33B/AFR 75-18/MCO P4610.19C and DLAR 4500.15.

#### 1-A.4. Reporting Errors and Recommending Improvements

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), direct to Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, NJ 07703. A reply will be furnished to you.

#### 1-A.5. Reporting Equipment Improvement Recommendations (EIR)

If your Electronic Voltmeter needs improvement, let us know. Send us an EIR. You, the user are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design. Tell us why a procedure is hard to perform. Put it on an SF 368 (Quality Deficiency Report). Mail it to Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, NJ 07703. We'll send you a reply.

#### 1-A.6. Administrative Storage

Administrative storage of this equipment consists of covering the equipment with heavy paper taped in a way to prevent entry of dust particles. If environment is humid, use bags of dessicant inside the paper covering.