

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND
SPECIAL TOOLS LIST FOR
TEST SET, GYRO STABILIZED PLATFORM AN/ASM-385

Headquarters, Department of the Army, Washington, D. C.

17 August 1971

TABLE OF CONTENTS

	Paragraph	Page
SECTION I. INTRODUCTION		
Scope	1-1	1-1
General	1-2	1-1
Explanation of Columns	1-3	1-1
Special Information	1-4	1-3
How to Locate Repair Parts	1-5	1-3
Abbreviations (Not Applicable)		1-4
Federal Supply Codes for Manufacturers	1-6	1-4
Recommendations for Maintenance Publication Improvements	1-8	1-4
SECTION II. PRESCRIBED LOAD ALLOWANCE		2-1
SECTION III. REPAIR PARTS FOR ORGANIZATIONAL MAINTENANCE		3-1
SECTION IV. SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT FOR ORGANIZATIONAL MAINTENANCE (Not Applicable)		4-1
SECTION V. INDICES		
Federal Stock Number Cross Reference to Index Number		5-1
Reference Number Cross-Reference to Figure and Item Number		5-2
Reference Designation Cross Reference to Index Number		5-3
Federal Stock Number Cross-Reference to Figure and Item Number		5-4
Figure and Item Number Cross Reference to Index Number		5-6

LIST OF ILLUSTRATIONS

Number	Title	Page
1	Test Set, Gyro Stabilized Platform AN/ASM-385	3-4
2	Control-Display Unit C-8316/ASJ	3-5
3	Control-Display Unit Subassembly	3-6
4	Switching Unit TS-2907/ASM-385	3-7
5	Electronics Unit Subassembly	3-8

SECTION I. INTRODUCTION

1-1. Scope.

This manual lists repair parts and special tools required for the performance of organizational maintenance of the Test Set, Gyro Stabilized Platform AN/ASM-385.

1-2. General.

This Repair Parts and Special Tools List is divided into the following sections:

Prescribed Load Allowance (PLA) - Section II. A composite listing of the repair parts, special tools, test and support equipment having quantitative allowances for initial stockage at the organizational level.

b. Repair Parts - Section III. A list of repair Parts authorized for the performance of maintenance at the organizational level in index number sequence.

c. Special Tools, Test and Support Equipment - Section IV. Not applicable.

d. Indices - Section V. Conversion of numbers and indices is explained as follows:

(1) Index - Federal Stock Number to Index Number. A list of Federal Stock numbers, in ascending numerical sequence, cross-referenced to the Repair Parts list index number.

(2) Index - Reference Number to Figure and Item Number. A list of reference numbers (part numbers and manufacturers codes), in ascending alphanumeric sequence, cross-referenced to figure and item number.

(3) Index - Reference Designation to Index Number. A list of Reference Designations (RD), in ascending alphanumeric sequence, cross-referenced to the Repair Parts list index number.

(4) Index - Federal Stock Number to Figure and Item Number. A list of Federal stock numbers, in ascending numerical sequence, cross-referenced to the illustration figure number and item number.

(5) Index — Figure and Item Number to Index Number. A list of figure and item numbers, each in ascending numerical sequence, cross-referenced to the Repair Parts list index numbers.

1-3. Explanation of Columns.

The following provides an explanation of columns in the tabular lists in Sections III and IV.

a. Source, Maintenance, and Recoverability (SMR) Codes, Column 1:

(i. Source code, indicates the selection status and source for the listed item. Source codes are

Code	Explanation
A	Applies to assemblies which are not procured or stocked as such but are made up of two or more units, each of which carry individual stock numbers and descriptions and are procured and stocked and can be assembled by units at indicated maintenance categories
AH	Applies to repair parts requiring assembly at a category higher than that authorized to replace the part
G	Applies to major assemblies that are procured with Procurement of Electronic and Missile, Army (PEMA) funds for initial issue only to be used as exchange assemblies at Direct Support Unit (DSU) and General Support Unit (GSU) level. These assemblies will not be stocked above DSU and GSU level or returned to depot level
P	Applies to repair parts which are stocked in or supplied from General Support Activity/Direct Support Activity (GSA/DSA), or Army supply system, and authorized for use at indicated maintenance categories