

T M 1 1 - 6 6 2 5 - 2 4 4 0 - 4 5 P

TECHNICAL MANUAL

GENERAL SUPPORT AND DEPOT REPAIR

PARTS AND SPECIAL TOOLS LIST

TEST SET, GYRO STABILIZED PLATFORM AN/ASM-385
(FSN 6625-404-3281)

HEADQUARTERS, DEPARTMENT OF THE ARMY
SEPTEMBER 1971

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

GENERAL SUPPORT AND DEPOT MAINTENANCE REPAIR
 PARTS AND SPECIAL TOOLS LIST FOR
 TEST SET, GYRO STABILIZED PLATFORM AN/ASM-385

Headquarters, Department of the Army, Washington, D.C.

28 September 1971

TABLE OF CONTENTS

	PARAGRAPH	PAGE
SECTION I.	INTRODUCTION	
	Scope	1-1
	General	1-2
	Explanation of Columns.	1-3
	Special Information	1-4
	How To Locate Repair Parts.	1-5
	Abbreviations (Not Applicable)	1-6
	Federal Supply Codes for Manufacturers	1-7
	Recommendations for Maintenance Publication Improvements	1-8
<i>SECTION II.</i>	REPAIR PARTS FOR GENERAL SUPPORT AND DEPOT MAINTENANCE	2-1
SECTION III.	SPECIAL TOOLS, TEST, AND SUPPORT EQUIPMENT FOR GENERAL SUPPORT AND DEPOT MAINTENANCE	3-1
SECTION IV.	INDICES	
	Federal Stock Number Cross Reference to Index Number	4-1
	Reference Number Cross-Reference to Figure and Item Number	4-10
	Reference Designation Cross Reference to Index Number	4-19
	Federal Stock Number Cross-Reference to Figure and Item Number	4-28
	Figure and Item Number Cross Reference to Index Number.	4-37

LIST OF ILLUSTRATIONS

Number		Page
1	Test Set, Gyro Stabilized Platform AN/ASM-385.	3-3
2	Control-Display Unit C-8316/AMS-385	3-4
3	Electrical Power Cable Assemblies CX-12107/U and CX-12108/U, and Electrical Special Purpose Cable Assemblies CX-12114/U, CX-12115/U, CX-12116/U, CX-12117/U, and CX-12118/U	3-5
4	Control-Display Unit Subassembly	3-7
5	Circuit Card Cage Assembly	3-11
6	Circuit Card Assembly	3-12
7	Circuit Card Assembly	3-13
8	Circuit Card Assembly	3-14
9	Circuit Card Assembly	3-15
10	Power Supply	3-16
11	5 VDC Switching Regulator and Crowbar	3-17
12	Transformer Rectifier	3-18
13	Switching Unit TS-2907/ASM-385	3-19
14	Electrical Special Purpose Cable Assemblies CX-12109/U CX-12110/U, CX-12111/U, CX-12112/U, CX-12113/U, CX-12119/U, and CX-12120/U	3-20
15	Electronics Unit Subassembly	3-23
16	Circuit Card Cage Assembly	3-26
17	Circuit Card Assembly	3-27
18	Circuit Card Assembly	3-28
19	Circuit Card Assembly	3-29
20	Circuit Card Assembly	3-30
21	Circuit Card Assembly	3-31
22	Circuit Card Assembly	3-32
23	Circuit Card Assembly	3-33
24	Circuit Card Assembly	3-34
25	Circuit Card Assembly	3-35
26	Circuit Card Assembly	3-36
27	Circuit Card Assembly	3-37
28	Circuit Card Assembly	3-38
29	Special Tools, Test, and Support Equipment.	3-39

GENERAL SUPPORT AND DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

Section I. INTRODUCTION

1-1. Scope.

This manual lists repair parts, special tools, and test and support equipment required for the performance of general support and depot maintenance of the Test Bet, Gyro Stabilized Platform AN/ASM-385. Direct support maintenance is not applicable to this manual, although tabular headings indicate same *for* consistency with associated manuals.

1-2. General.

This Repair Parts and Special Tools list is divided into the following sections:

Repair Parts -Section II. A list of repair parts authorized for the performance of maintenance at the direct support, general support, and depot level in the same sequence as the Selection Work Sheet. Figure and item numbers are not in sequential order.

b. Special Tools, Test, and Support Equipment -Section III. A list of special tools, test, and support equipment authorized for the performance of maintenance at the direct support, general support, and depot level.

C. Indices - Section IV. Conversion of numbers and indices is explained as follows:

(1) Index - Federal Stock Number to Index Number. A list of Federal stock numbers, in ascending numerical sequence, cross-referenced to the Repair Parts list index number.

(2) Index - Reference Number to Figure and Item Number. A list of reference numbers (part numbers and manufacturers codes), in ascending alphanumeric sequence, cross-referenced to figure and item number.

(3) Index - Reference Designation to Index Number. A list of Reference Designations (RD), in ascending alphanumeric sequence, cross-referenced to the Repair Parts list index number.

(4) Index - Federal Stock Number to Figure and Item Number. A list of Federal stock numbers, in ascending numerical sequence, cross-referenced to the illustration figure number and item number.

(5) Index - Figure and Item Number to Index Number. A list of figure and item numbers, each in ascending numerical sequence, cross-referenced to the Repair Parts list index numbers.

1-3. Explanation of Columns.

The following provides an explanation of columns in the tabular lists in Sections II and III.

a. Source, Maintenance, and Recoverability (SMP) Codes, Column 1.

(1) Source code, indicates the selection status and source for the listed item. Source codes are:

<i>Code</i>	Explanation
A	Applies to assemblies which are not procured or stocked as such but are made up of two or more units, each of which carry individual stock numbers and descriptions and are procured and stocked and can be assembled by units at indicated maintenance categories
AD	Applies to repair parts requiring assembly at a category higher than that authorized to replace the part
G	Applies to major assemblies that are procured with Procurement of Electronics and Missiles, Army (PEMA) funds for initial issue only to be used as exchange assemblies at Direct Support Unit (DSU) and General Support Unit (GSU) level
M	Applies to repair parts which are not procured or stocked but are to be manufactured at indicated maintenance categories