

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

GENERAL SUPPORT AND DEPOT MAINTENANCE REPAIR
 PARTS AND SPECIAL TOOLS LIST FOR
 PURGE AND FILL UNIT, GYRO STABILIZED PLATFORM MX-8474/ASN-86

Headquarters, Department of the Army, Washington, D. C.

17 August 1971

TABLE OF CONTENTS

	Paragraph	Page
SECTION I. INTRODUCTION		
Scope	1-1	1-1
General	1-2	1-1
Explanation of Columns	1-3	1-1
Special Information	1-4	1-3
How to Locate Repair Parts	1-5	1-3
Abbreviations (Not Applicable).....	1-6	1-4
Federal Supply Codes for Manufacturers	1-7	1-4
Recommendations for Maintenance Publication Improvements.....	1-8	1-6
II. REPAIR PARTS FOR GENERAL SUPPORT AND DEPOT MAINTENANCE		2-1
III. SPECIAL TOOLS, TEST, AND SUPPORT EQUIPMENT FOR GENERAL SUPPORT AND DEPOT MAINTENANCE		3-1
IV. INDICES		
Federal Stock Number Cross-Reference to Index Number		4-1
Reference Number Cross-Reference to Figure and Item Number		4-2
Reference Designation Cross-Reference to Index Number		4-3
Federal Stock Number Cross-Reference to Figure and Item Number		4-4
Figure and Item Number Cross-Reference to Index Number		4-5

LIST OF ILLUSTRATIONS

Number	Title	Page
1	Purge and Fill Unit, Gyro Stabilized Platform MX-8474/ASN-86	3-2
2	Special Tools, Test, and Support Equipment	3-3

Section I. INTRODUCTION

1-1. Scope.

This manual lists repair parts, special tools, and test and support equipment required for the performance of general support and depot maintenance of the Purge and Fill Unit, Gyro Stabilized Platform MX-8474/ASN-86. Direct support maintenance is not applicable to this manual, although tabular headings indicate same for consistency with associated manuals.

1-2. General.

This Repair Parts and Special Tools list is divided into the following sections:

a. Repair Parts Section II. A list of repair parts authorized for the performance of maintenance at the general support and depot level in the same sequence as the Selection Work Sheet. Figure and item numbers are not in sequential order.

b. Special Tools, Test, and Support Equipment Section III. A list of special tools, test, and support equipment authorized for the performance of maintenance at the general support, and depot level.

c. Indices Section IV. Conversion of numbers and indices is explained as follows:

(1) Index Federal Stock Number to Index Number. A list of Federal stock numbers, in ascending numerical sequence, cross-referenced to the Repair Parts list index number.

(2) Index Reference Number to Figure and Item Number. A list of reference numbers (part numbers and manufacturers codes), in ascending alphanumeric sequence, cross-referenced to figure and item number.

(3) Index -Reference Designation to Index Number. A list of Reference Designations (RD), in ascending alphanumeric sequence, cross-referenced to the Repair Parts list index number.

(4) Index Federal Stock Number to Figure and Item Number. A list of Federal stock numbers, in ascending numerical sequence, cross-referenced to the illustration figure number and item number.

(5) Index Figure and Item Number to Index Number. A list of figure and item numbers, each in ascending numerical sequence, cross-referenced to the Repair Parts list index numbers.

1-3. Explanation of Columns.

The following provides an explanation of columns in the tabular lists in Sections II and III.

a. Source, Maintenance, and Recoverability (SMR) Codes, Column 1.

(1) Source code, indicates the selection status and source for the listed item. Source codes are:

Code	Explanation
G	Applies to major assemblies that are procured with Procurement of Electronics and Missiles, Army (PEMA) funds for initial issue only to be used as exchange assemblies at Direct Support Unit (DSU) and General Support Unit (GSU) level. These assemblies will not be stocked above DSU and GSU level or returned to depot level
P	Applies to repair parts which are stocked in or supplied from the General Support Activity/Direct Support Activity (GSA/DSA), or Army supply system, and authorized for use at indicated maintenance categories
X2	Applies to repair parts which are not stocked. The indicated maintenance category requiring such repair parts will attempt to obtain through cannibalization; if not obtainable through cannibalization, such repair parts will be requisitioned with supporting justification through normal supply channels