

**ARMY TM 11-6625-2735-14
NAVY NAVELEX 0969-LP-170-1090
AIR FORCE TO 33A1-13-498-1**

**OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT,
AND GENERAL SUPPORT MAINTENANCE MANUAL
(INCLUDING DEPOT MAINTENANCE)
FOR
OSCILLOSCOPE 0S-261/U
(NSN 6625-00-127-0079)**

**DEPARTMENTS OF THE ARMY, THE NAVY, AND THE AIR FORCE
26 MARCH 1979**

Technical Manual
No. 11-6625-2735-14
Technical Manual
NAVELEX 0969-LP-170-1090
Technical Order
TO 33A1-13-498-1

DEPARTMENTS OF THE ARMY, THE NAVY,
AND THE AIR FORCE

Washington, DC, 26 March 1979

OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT,
GENERAL SUPPORT, AND DEPOT MAINTENANCE
MANUAL
FOR
OSCILLOSCOPE OS-261/U
(NSN 6625-00-127-0079)

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 2028-2 located in the back of the manual. Simply tear out the self-addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Forms 2028-2 in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forwarded to the Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, NJ 07703.

For Air Force, submit AFTO Form 22 (Technical Order System Publication Improvement Report and Reply) in accordance with paragraph 6-5, Section VI, T.O. 00-5-1. Forward direct to prime ALC/MST.

For Navy, mail comments to the Commander, Naval Electronics Systems Command, Training and Publications Management Office, ELEX 04F3, P.O. Box 80337, San Diego, California 92138.

In either case, a reply will be furnished direct to you.

TABLE OF CONTENTS

	Page
Section 0	INTRODUCTION
	scope0-1
	Indexes of Publications0-1
	Forms and Records0-1
	Reporting Equipment Improvement Recommendations (EIR)0-1
	Administrative Storage0-1
	Destruction of Army Electronics Materiel 0-1
Section 1	SPECIFICATION
	Introduction1-1
	Vertical Deflection System1-1
	Triggering 1-1
	Horizontal Deflection System 1-2
	X-Y operation 1-3
	Calibrator1-3
	Z Axis Input 1-3

TABLE OF CONTENTS

		Page
	Signal Outputs.....	1-3
	Power Source.....	1-3
	Cathode-Ray Tube.....	1-4
	Environmental.....	1-4
	Supplemental Information.....	1-4
Section 2	OPERATING INFORMATION	
	Introduction.....	2-1
	Operating Voltage.....	2-1
	Controls And Connectors	
	General.....	2-2
	Cathode-Ray Tube (CRT) and Display.....	2-2
	Vertical Deflection System.....	2-2
	A and B Triggering.....	2-4
	A and B Sweep.....	2-5
	Calibrator and Power.....	2-6
	Rear Panel.....	2-6
	Obtaining Basic Displays	
	introduction.....	2-6
	Normal Sweep Display.....	2-6
	Magnified Sweep Display.....	2-7
	Delayed Sweep Display.....	2-7
	Mixed Sweep Display.....	2-7
	X-Y Display.....	2-7
Section 3	CIRCUIT DESCRIPTION	
	Introduction.....	3-1
	Digital Logic.....	3-1
	Block Diagram.....	3-2
	General.....	3-2
	Channel 1 Preamp.....	3-3
	General.....	3-3
	Input Coupling.....	3-3
	Input Attenuator.....	3-3
	First Cascade Amplifier.....	3-4
	Second Cascade Amplifier.....	3-4
	Third Cascade Amplifier.....	3-4
	Channel 2 Preamp.....	3-5
	General.....	3-5
	First Cascade Amplifier.....	3-5
	Vertical Channel Switching Circuit.....	3-5
	General.....	3-5
	Channel Switch IC.....	3-5
	Switching Logic Flip-Flops.....	3-6
	Two-Megahertz Clock.....	3-6
	Chop Blanking Amplifier.....	3-7
	Channel 2 Signal Output Amplifier.....	3-7
	Normal Trigger Pickoff Amplifier.....	3-7
	Scale-Factor Switching Circuits.....	3-7
	Vertical Output Amplifier.....	3-7
	General.....	3-7
	First IC Amplifier.....	3-7
	Second IC Amplifier.....	3-7
	A Trigger Generator.....	3-7
	General.....	3-7
	Trigger Source.....	3-8
	Trigger Coupling.....	3-8
	Input Source Follower.....	3-8
	Paraphase Amplifier.....	3-8
	Tunnel Diode Driver.....	3-9
	Trigger View Amplifier.....	3-9
	B Trigger Generator.....	3-9
	General.....	3-9
	Trigger Source.....	3-9

TABLE OF CONTENTS


	Page
Sweep And Z Axis Logic Circuit	3-9
General	3-9
Sweep Control IC	3-9
Main Gate Comparator	3-10
Delayed Gate Comparator	3-10
A Trigger TD Reset Circuit	3-10
Holdoff Start Circuit	3-10
Z Axis Logic Multivibrator	3-11
Delayed Sweep Latch	3-11
B Trigger TD Reset Circuit	3-11
Delayed Sweep Override Amplifier.	3-11
A + Gate And B + Gate Amplifiers.	3-11
Sweep Generators	3-12
General	3-12
Delaying Sweep Generator	3-12
Main Gate Amplifier	3-12
Sweep Disconnect Amplifier	3-12
Sawtooth Sweep Generator	3-13
Sweep Start Amplifier	3-13
Output Buffer Amplifier	3-13
Logic Comparator	3-13
Delay Pickoff Comparator	3-13
Non-Delaying Sweep Generators.	3-14
“B” Gate Amplifier	3-14
Non-Delaying Sweep Generator Differences	3-14
Mixed Mode Operation	3-14
Logic Comparator	3-14
Horizontal Amplifier	3-15
General	3-15
Input Paraphase Amplifier	3-15
Gain Setting Amplifier	3-15
Output Amplifier	3-16
Low-Voltage Power Supply	3-16
General	3-16
Power Input	3-16
Secondary Circuit	3-16
CRT Circuit	3-16
General	3-16
High-Voltage Oscillator	3-16
High-Voltage Regulator	3-18
High-Voltage Rectifiers and Output	3-19
CRT Control Circuits	3-19
Z-Axis Amplifier	3-19
DC Restorer Circuit	3-20
Calibrator	3-20
General	3-20
Multivibrator	3-20
Output Amplifier	3-20
Fan Motor Circuit	3-20
General	3-20

Section 4

MAINTENANCE	
Cabinet Removal	4-1
Preventive Maintenance	
General	4-1
Cleaning	4-1
Lubrication	4-2
Transistor Checks	4-2
Recalibration	4-2
Corrective Maintenance	
General	4-2
Obtaining Replacement Parts	4-2
Soldering Techniques	4-3
Component Replacement	4-3
Vertical Preamp Circuit Board Removal	4-3

TABLE OF CONTENTS

		Page
	Vertical Mode Switch Circuit Board Removal	4-4
	Trigger Generator And Sweep Logic Circuit Board Removal	4-4
	Sweep Timing Circuit Board Removal	4-4
	Recalibration After Repair	4-5
	Instrument Repackaging	4-5
Section 5	CALIBRATION	
	Calibration Interval	5-1
	Tektronix Field Service	5-1
	Using This Procedure	5-1
	Test Equipment Required	5-1
	General	5-1
	Special Calibration Fixtures	5-1
	Calibration Equipment Alternatives	5-1
	Preliminary Control Settings	5-4
	Performance Check	5-5
	Introduction	5-5
	Index	5-5
	Preliminary Procedure	5-5
	Vertical System Check	5-6
	Trigger System Check	5-9
	Horizontal System Check	5-11
	Short-Form Calibration	5-14
	Introduction	5-14
	Preliminary Procedure	5-14
	Power Supplies & Display Calibration	5-14
	Vertical System Calibration	5-15
	Trigger System Calibration	5-18
	Horizontal System Calibration..	5-19
	Calibration	5-23
	Introduction	5-23
	Index	5-23
	Preliminary Procedure	5-24
	Power Supply Calibration	5-25
	Display & Z-Axis Calibration	5-26
	Vertical System Calibration	5-28
	Trigger System Calibration	5-40
	Horizontal System Calibration..	5-49
	Calibrator, + Gates, & External Z-Axis Calibration	5-59
Section 6	ELECTRICAL PARTS LIST	
Section 7	DIAGRAMS AND CIRCUIT BOARD ILLUSTRATIONS	
Section 8	MECHANICAL PARTS LIST AND ILLUSTRATIONS	
Appendix A.	REFERENCES	A-1
	B. COMPONENTS OF END ITEM LIST (COEIL) (Not applicable)	
	C. ADDITIONAL AUTHORIZATION LIST (AAL) (Not applicable)	
	D. MAINTENANCE ALLOCATION	
Section	I. Introduction	D-1
	II. Maintenance allocation chart.....	D-5
	III. Tool and Test Equipment Requirements	D-6
	IV. Remarks	D-7
Appendix E.	EXPENDABLE SUPPLIES AND MATERIALS LIST (ES&ML)	
	(Not applicable)	



475 Oscilloscope

SECTION 0 INTRODUCTION

0-1. Scope

This manual contains instructions for the operation and organizational, direct support, general support and depot maintenance of Oscilloscope OS-261/U. Throughout this manual Oscilloscope OS-261/U is referred to as oscilloscope 475.

0-2. Indexes of Publications

a. DA Pam 310-4. Refer to the latest issue of DA Pam 310-4 to determine whether there are new editions, changes, or additional publications pertaining to the equipment.

b. DA Pam 310-7. Refer to DA Pam 310-7 to determine whether there are modification work orders (MWO's) pertaining to the equipment.

0-3. Forms and Records

a. Reports of Maintenance and Unsatisfactory Equipment. Maintenance forms, records, and reports which are to be used by maintenance personnel at all maintenance levels are listed in and prescribed by TM 38-750 (Army). Air Force personnel will use AFM 66-1 for maintenance reporting and TO-00-35D54 for unsatisfactory equipment reporting. Navy personnel will report maintenance performed utilizing the Maintenance Data Collection Subsystem (MDCS) IAW OPNAVINST 4790.2, Vol 3 and unsatisfactory material/conditions (UR submission) IAW OPNAVINST 4790.2, Vol 2, chapter 17.

b. Report of Packaging and Handling Deficiencies. Fill out and forward DD Form 6 (Packaging Improvement Report) as prescribed in AR 700-58/NAVSUPINST 4030.29/AFR 71-13/MCO P4030.29A, and DSAR 4145.8.