

TM 11-6625-2835-14&P

---

TECHNICAL MANUAL

OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT,  
AND GENERAL SUPPORT MAINTENANCE MANUAL  
INCLUDING REPAIR PARTS AND SPECIAL TOOLS LISTS  
FOR

PULSE GENERATOR SG - 1105/U  
(HEWLETT-PACKARD MODEL 8013B)  
(NSN 6625-01-010-3524)

---

HEADQUARTERS, DEPARTMENT OF THE ARMY

27 JUNE 1979

TECHNICAL MANUAL }  
NO. 11-6625-2835-14&P }

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, DC, 27 June 1979

OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT,  
AND GENERAL SUPPORT MAINTENANCE MANUAL  
INCLUDING REPAIR PARTS AND SPECIAL TOOLS LISTS  
FOR

PULSE GENERATOR SG-1105/U  
(HEWLETT- PACKARD MODEL 8013B)  
(NSN 6625-01-010-3524)

**REPORTING OF ERRORS**

**You can improve this manual by recommending improvements using DA Form 2028-2 located in the back of the manual. Simply tear out the self-addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.**

**If there are no blank DA Forms 2028-2 in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, NJ 07703.**

**In either case a reply will be furnished direct to you.**

This manual is an authentication of the manufacturer's commercial literature which, through usage, has been found to cover the data required to operate and maintain this equipment. Since the manual was not prepared in accordance with military specifications, the format has not been structured to consider levels of maintenance.

**CONTENTS**

<b>Section 0</b>	<b>Introduction</b>	<b>Page</b>
Section 1	General Information	
1-1	Introduction . . . . .	1-1
Section 2	Installation	
2-1	Initial Inspection . . . . .	2-1
2-5	Claims for Damage . . . . .	2-1
2-7	Repacking . . . . .	2-1
2-9	Preparation for Use . . . . .	2-2
2-10	Power Cord . . . . .	2-2
2-13	Power Source Requirements . . . . .	2-2
2-17	Temperature Requirements . . . . .	2-2
2-19	Rack Mounting . . . . .	2-2
Section 3	Operating Instructions	
3-1	General . . . . .	3-1
3-3	Output Formats . . . . .	3-1
3-6	Internal 50 Ohm Load . . . . .	3-1
3-8	Control Layout . . . . .	3-1
3-11	Norm Operating Mode . . . . .	3-2
3-13	Internal Trigger . . . . .	3-2
3-18	External Trigger . . . . .	3-4
3-23	Manual Trigger . . . . .	3-5
3-28	Square Wave Mode . . . . .	3-7
3-34	Gating Mode . . . . .	3-9
3-38	RZ Mode . . . . .	3-10
3-44	Double Pulse Mode . . . . .	3-11
3-49	External Width Mode . . . . .	3-13
3-54	Additional Facilities in RZ and Ext Width Modes . . . . .	3-14
Section 4	Theory of Operation	
4-1	Introduction . . . . .	4-1
4-9	Repetition Rate Generator . . . . .	4-2
4-12	Internal Rate Generator . . . . .	4-2
4-14	External Trigger Operatiog . . . . .	4-2
4-16	Manual Operation . . . . .	4-2
4-18	Gating . . . . .	4-2
4-20	Selector Circuits . . . . .	4-2
4-26	Delay Generator . . . . .	4-4
4-31	Width Generator . . . . .	4-5
4-37	Output Amplifiers . . . . .	4-5
4-43	Offsets and Attenuators . . . . .	4-7
4-48	Power Supplies . . . . .	4-7

## CONTENTS

Section		Page
Section 5	Maintenance	
5-1	General . . . . .	5-1
5-4	Removal of covers . . . . .	5-1
5-6	Removal of Assemblies . . . . .	5-1
5-8	Timing board – Assembly 5 . . . . .	5-1
5-10	Output board – Assembly 6. . . . .	5-1
5-15	Motherboard – Assembly 7 . . . . .	5-1
5-23	Performance Tests . . . . .	5-1
5-25	internal Checks and Adjustments . . . . .	5-2
5-27	Service Product Safety Check . . . . .	5-2
Section 6	Diagrams and Replaceable Parts	
6-1	Introduction . . . . .	6-1
6-3	Ordering Information . . . . .	6-1
6-4	General . . . . .	6-1

## TABLES

Table	Title	
1-1	Specifications . . . . .	1-2
5-1	Test Equipment and Accessories . . . . .	5-3
5-2	Performance Test: Pulse Period. . . . .	5-4
5-3	Performance Test: Pulse Delay. . . . .	5-4
5-4	Performance Test: Pulse Width (greater than 1 $\mu$ s) . . . . .	5-5
5-5	Performance Test: Minimum Pulse Width . . . . .	5-5
5-6	Performance Test: Pulse Period Jitter . . . . .	5-6
5-7	Performance Test: Pulse Delay Jitter . . . . .	5-6
5-8	Performance Test: Pulse Width Jitter . . . . .	5-7
5-9	Performance Test: Square Wave . . . . .	5-7
5-10	Performance Test: Duty Cycle. . . . .	5-8
5-11	Performance Test: Manual Operation . . . . .	5-8
5-12	Performance Test: External Width Operation . . . . .	5-9
5-13	Performance Test: RZ Operation . . . . .	5-9
5-14	Performance Test: Gate Operation . . . . .	5-10
5-15	Performance Test: External Trigger Operation . . . . .	5-10
5-16	Performance Test: High Frequency Trigger Operation . . . . .	5-11
5-17	Performance Test: Trigger Output . . . . .	5-11
5-18	Performance Test: Preshoot, Overshoot and Ringing . . . . .	5-12
5-19	Performance Test: Amplitude. . . . .	5-12
5-20	Performance Test: DC Offset. . . . .	5-13
5-21	Internal Checks and Adjustments – Power Supply . . . . .	5-13
5-22	Internal Checks and Adjustments – Repetition Rate . . . . .	5-14
5-23	Internal Checks and Adjustments - Delay and Width Timing . . . . .	5-14
5-24	Internal Checks and Adjustments - Pulse Perturbation . . . . .	5-15
5-25	Internal Checks and Adjustments - Double Pulse . . . . .	5-16
5-26	Service Product Safety Check . . . . .	5-18
6-1	Reference Designators . . . . .	6-1
6-2	Diagram Notes . . . . .	6-2
6-3	Manufacturers Codes . . . . .	6-3
6-4	Frame Replaceable Parts List . . . . .	6-5
6-5	Board A5 Replaceable Parts List . . . . .	6-7
6-6	Board A6 Replaceable Parts List. . . . .	6-13
6-7	Board A7 Replaceable Parts List . . . . .	6-17
6-8	Part Number-National Stock Number Cross Reference Index . . . . .	6-32

**ILLUSTRATIONS**

Figure	Title	Page
2-1	8013 Band Supplied Accessories . . . . .	2-0
2-2	Power Cords . . . . .	2-1
2-3	Selector settings for the nominal power line voltages . . . . .	2-2
3-1	80136 Front and rear panels –Control identification diagram . . . . .	3-0
3-2	Normal/Complement Outputs . . . . .	3-1
3-3	Positioning of Controls . . . . .	3-2
3-4	Initial Control Settings and Test Equipment . . . . .	3-3
3-5	Normal Internal Trigger Mode – Block Diagram . . . . .	3-3
3-6	Output Pulses in Normal Internal Trigger Mode . . . . .	3-4
3-7	Normal External Trigger Mode – Block Diagram . . . . .	3-5
3-8	Output Pulses in Normal External Trigger Mode . . . . .	3-6
3-9	Normal Manual Trigger Mode – Block Diagram . . . . .	3-6
3-10	Output Pulses in Normal Manual Trigger Mode . . . . .	3-7
3-11	Normal Square Wave Mode – Block Diagram . . . . .	3-8
3-12	Output Pulses in Square Wave Mode . . . . .	3-8
3-13	Normal Gate Mode – Block Diagram . . . . .	3-9
3-14	Output Pulses in Gate Mode . . . . .	3-10
3-15	R Z Mode – Block Diagram . . . . .	3-10
3-16	Output Pulses in RZ Mode . . . . .	3-11
3-17	Double Pulse Mode – Block Diagram . . . . .	3-12
3-18	Output Pulses in Double Pulse Mode . . . . .	3-12
3-19	External Width Mode – Block Diagram . . . . .	3-13
3-20	Output Pulses in External Width Mode . . . . .	3-14
3-21	Independent Clock Generator in RZ/EXT WIDTH Modes – Block Diagram . . . . .	3-14
4-1	80136 Pulse Generator – Block Diagram . . . . .	4-0
4-2	Repetition Rate Generator – Block Diagram . . . . .	4-1
4-3a	Normal Mode (including external trigger and rate mode) . . . . .	4-2
4-3b	RZ Mode . . . . .	4-3
4-3c	Ext Width Mode . . . . .	4-3
4-3d	Square Wave Mode . . . . .	4-4
4-4	Delay Generator – Block Diagram . . . . .	4-4
4-5	Width Generator – Block Diagram . . . . .	4-5
4-6	Output Amplifiers – Block Diagram . . . . .	4-6
4-7	Offsets and Attenuators – Block Diagram . . . . .	4-6
6-1	Assembly Diagram . . . . .	6-4
6-2	Component Layout - Board A5 . . . . .	6-6
6-3	Component Layout - Board A6 . . . . .	6-8
6-4	Component Layout - Board A7 - Front View . . . . .	6-10
6-5	Component Layout - Board A7 – Rear View . . . . .	6-11
 Diagrams		 Page
1	Repetition Rate Generator 8012B/8013B . . . . .	6-13
2	Mode Selector, Trigger Amplifier, Ext. Input and Square Wave Circuits . . . . .	6-15
3	Delay Generator 8012B/8013B . . . . .	6-17
4	Width Generator 8012B/8013B . . . . .	6-19
5	Output Amplifiers 8013B . . . . .	6-21
6	Offset and Attenuator 8013B . . . . .	6-23
7	Power Supplies 8013B . . . . .	6-25

APPENDIXES

Appendix	Title	Page
A	References . . . . .	A-1
B	Components of End Item List . . . . .	B-1
C	Additional Authorization List (Nonapplicable)	
D	Maintenance Allocation . . . . .	D-1
E	Expendable Supplies and Materials List (Not Applicable)	
F	Repair Parts and Special Tools List . . . . .	F-1

## SECTION 0

### INTRODUCTION

---

#### 0-1. Scope

This manual describes Pulse Generator SG-1105/U and provides instructions for operation and maintenance. Throughout this manual, the SG-1105/U is referred to as Hewlett-Packard Model 8013B.

#### 0-2. Indexes of Publications

*a. DA Pam 910-4.* Refer to the latest issue of DA Pam 310-4 to determine whether there are new editions, changes, or additional publications pertaining to the equipment.

*b. DA Pam 310-7.* Refer to DA Pam 310-7 to determine whether there are modification work orders (MWO's) pertaining to the equipment.

#### 0-3. Forms and Records

*a. Reports of Maintenance and Unsatisfactory Equipment.* Maintenance forms, records, and reports which are to be used by maintenance personnel at all maintenance levels are listed in and prescribed by TM 38-750.

*b. Report of Packaging and Handling Deficiencies.* Fill out and forward DD Form 6 (Packaging Improvement Report) as prescribed in AR 700-58/NAVSUPINST 4030.29/AFR 71-13/MCO P4030.29A and DSAR 4145.8.

*c. Discrepancy in Shipment Report (DISREP) (SF 361).* Fill out and forward Discrepancy in Shipment Report (DISREP) (SF 361) as prescribed in AR 55-38/NAVSUPINST 4610.33B/AFR 75-18/MCO P4610.19C and DLAR 4500.15.

#### 0-4. Reporting Equipment Improvement Recommendations (EIR)

EIR's will be prepared using Standard Form 368, Quality Deficiency Report. Instructions for preparing EIR's are provided in TM 38-750, The Army Maintenance Management System, EIR's should be mailed direct to Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, NJ 07703. A reply will be furnished direct to you.

#### 0-5. Administrative Storage

To prepare the equipment for administrative storage, ascertain its operability and reliability. In addition, use the proper packing materials.

#### 0-6. Destruction of Army Electronics Materiel

Destruction of Army electronics materiel to prevent enemy use shall be in accordance with TM 750-244-2.