

TM 11-6625-2885-12 NAVAIR 16-35TS361 4-1 DEPARTMENTS OF THE ARMY AND THE NAVY Washington, DC, 23 February 1984

OPERATOR'S AND AVIATION UNIT MAINTENANCE MANUAL

TEST SET, COUNTERMEASURES SET TS-3614/ALQ-136(V) (NSN 6625-01-121-8983)

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, US Army Communications-Electronics Command and Fort Monmouth, ATTN: DRSEL-ME-MP Fort Monmouth, N.J. 07703.

For Navy, mail comments or OP NAV 4790/66 (TECHNICAL PUBLICATIONS DEFICIENCY REPORT) to NAVAL TECHNICAL SERVICES FACILITY, 700 Robbins Avenue, ATTN CODE 04, Philadelphia, PA 19111.

In either case a reply will be furnished.

TM 11-6625-2885-12/NAVAIR 16-35TS3614-1

| | | PAGE |
|---------------------------------|--|-------------------------------------|
| | HOW TO USE THIS MANUAL | iii |
| CHAPTER 1 Section I II | INTRODUCTION. General Information. Equipment Description Technical Principles of Operation | 1-1 1-1 . 1-6 . 1-12 |
| CHAPTER 2 | OPERATING INSTRUCTIONS Description and Use of Operator's Controls and Indicators | . 2-1 2-1 |
| CHAPTER 3 Section I | MAINTENANCE INSTRUCTIONS Repair Parts, Special Tools; Test, Measurement, and Diagnostic Equipment (TMDE); and Support | 3-1 |
| | Equi pment | . 3-3 3-4 |
| APPENDIX A. | References | . A-1 |
| APPENDIX B. Section I II III IV | Maintenance Allocation Introduction Maintenance Allocation Chart Tools and Test Equipment Requirements Remarks | B-1 B-1 B-6 B-7 B-8 |
| APPENDIX C. Section I 11 | Components of End Item List Introduction Components of End Item | |
| APPENDIX D. | Additional Authorization List (Not Applicable) | |
| APPENDIX E. Section I | Expendable Supplies and Materials List Introduction Expendable Supplies and Materials | E-1 E-1 E-2 |
| | Index | Index- |

HOW TO USE THIS MANUAL

This manual tells you about operating, and maintaining the TS-3614/ALQ-136(V) Flight Line Test Set (FLTS) at the Aviation Unit Maintenance (AVUM) level. You'll find descriptions as well as operational level maintenance instructions for the FLTS.

Operators should also consult TM 11-5865-202-12 for Countermeasures Set AN/ALQ-136(V)1 instructions concerning operation of this equipment.

For your convenience, this manual has been divided into chapters, sections, and paragraphs which are numbered sequentially. In addition to this numbering system, a system of captions appears in BROWN print to help quickly find the information you need. These captions name the pieces of equipment and/or maintenance procedures that you will be doing. Some of the procedures may consist of several smaller procedures. The captions for these smaller procedures appear under the larger ones; both appear on each page as they are continued. Each large section begins with a "Section Contents" which lists the procedures by title and page number. Tables are numbered sequentially by chapter; illustrations are integrated into the text to which they apply.


NO ONE EVER REPAIRED OR TESTED ELECTRONIC EQUIPMENT WITHOUT FIRST READING THE OPERATION AND MAINTENANCE MANUAL.

IT IS THE MOST

IMPORTANT TOOL

YOU HAVE!!!





FLTS VIDEO ASSEMBLY 1A2

CHAPTER I INTRODUCTION

SECTION I GENERAL INFORMATION

| SECTION CONTENTS | PAGE |
|--|-------|
| SCOPE | 1-1 |
| ONSOLIDATED INDEX OF ARMY PUBLICATIONS AND BLANK FORMS | 1-2 |
| AINTENANCE FORMS , RECORDS, AND REPORTS | |
| AND RECEIPT (-HR) MANUAL | 1-2 |
| EPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIR) | 1-3 |
| ESTRUCTION OF ARMY ELECTRONICS MATERIEL TO PREVENT ENEMY USE | 1 - 4 |
| REPARATION FOR STORAGE OR SHIPMENT | 1-4 |
| OMENCLATURE CROSS-REFERENCE LIST | |
| IST OF ABBREVIATIONS | 1-5 |

SCOPE

1-1. This is one of a series of technical manuals covering the operation and maintenance of the AN/ALQ-136(V)1 Countermeasures Set. It is to be used by Aviation Unit Maintenance (AVUM) personnel responsible for maintaining the AN/ALQ-136(V)1.

This manual contains physical and functional descriptions, maintenance procedures, and instructions for inspection and servicing.

Model Number and

Equipment Name: Test Set, Countermeasures Set TS-3614/ALQ-136(V).

Purpose of

Equipment: To test Countermeasures Set AN/ALQ-136(V)1 without

removing it from aircraft.