TECHNICAL MANUAL

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS

FOR

SYNTHESIZER, FUNCTION GENERATOR (HEWLETT-PACKARD 3325A)

HEADQUARTERS, DEPARTMENT OF THE ARMY

9 OCTOBER 1984

Technical Manual

No. 11-6625-3065-24P)

HEADQUARTERS DEPARTMENT OF THE ARMY Washington, DC, 9 October 1984

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST FOR SYNTHESIZER, FUNCTION GENERATOR 3325A (HP)

Current as of 28 June 1984

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in back of this manual direct to: Commander, US Army Communications Electronics Command and Fort Monmouth, ATTN: DRSEL-ME-MP, Fort Monmouth, NJ 07703-5007.

In either case, a reply will be furnished direct to you.

Table of Contents

			Page	Illus Figure
Section	I.	Introduction	1	
	II.	Repair Parts List	5	
Group	00	Synthesizer, Function Generator 3325A (HP)		1
	01	Power Supply Assy 03325-66502 A2 (No parts authorized)		
	02	Signal Source Assy 03325-66503 A3 (No parts authorized)		
	03	Keyboard Assy 03325-66505 A5 (No parts authorized)		
	04	Control Assy 03325-66506 A6 (No parts authorized)		
	05	Attenuator Assy 03325-66507 A7 (No parts authorized)		
	06	Output Assy, HV 03325-66508 A8 (No parts authorized)		
	07	Oven Assy, Crystal 03325-66509 A9 (No parts authorized)		
	08	Function Assy 03325-66514 A14	9	2
	09	PC Assy, FFS D/A 03325-66521 A21 (No parts authorized)		
Section	III.	Special Tools List (Not applicable)		
	IV.	National Stock Number and Part Number Index	10	

i/(ii blank)

SECTION I

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational, direct support, and general support maintenance of the 3325A (HP). It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

<u>a</u>. <u>Section II. Repair Parts List</u>. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. Not applicable.

<u>c</u>. <u>Section IV. National Stock Number and Part Number Index</u>. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphanumeric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

- <u>a</u>. <u>Illustration</u>. This column is divided as follows:
 - (1) Figure number. Indicates the figure number of the illustration on which the item is shown.
 - (2) Item number. The number used to identify item called out in the illustration.
- b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) Source code. Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

<u>Code</u>

Definition

PA -- Item procured and stocked for anticipated or known usage.

PB -- Item procured and stocked for insurance purpose because essentially dictates that a minimum quantity be available in the supply system.

1