

TUG, HARBOR, DIESEL, 1200 H. P. STEEL, 1 - FT DESIGN 3006
(HULL NUMBERS LT 1936 THRU LT 1977 AND LT 2202)

Reference FEDERAL SUPPLY CATALOG C9100-IL, LO55-1925-204-12-1, 2, 4, 5, 6, 7, 8, TM55-1925-204-12 and TM55-1925-204-34

Intervals are based on normal hours of operations. Adjust to compensate for abnormal operations and severe conditions. During inactive periods, sufficient lubrication must be performed for adequate preservation. Clean fittings before lubricating.

Clean parts with SOLVENT, Dry-cleaning, Type II, (SD-2). Dry before lubricating.

Lubricate points indicated by dotted arrow shafts on both sides of equipment.

Drain wet crankcases, gear boxes and hydraulic reservoirs while the lubricant is still warm from previous use. Refill and check level.

FOLD

FOLD

