

**TECHNICAL MANUAL**

**GS MAINTENANCE MANUAL**

**TEST SET, CONVERTER**

**SUBASSEMBLY-VIDEO**

**CONVERTER AN/AAM-35**

**(NSN 6625-00-403-1064)**

**This copy is a reprint which includes current pages from Changes 1 through 3**

---

**HEADQUARTERS, DEPARTMENT OF THE ARMY**

**NOVEMBER 1970**

**GENERAL SUPPORT MAINTENANCE MANUAL**  
**TEST SET, CONVERTER SUBASSEMBLY-VIDEO CONVERTER**  
**AN/AAM-35**  
**(NSN 6625-00-403-1064)**

		Paragraph	Pages
CHAPTER	1.	INTRODUCTION	
		Scope of Manual .....	1-1
		Indexes of Publications.....	1-1
		Reporting of errors.....	1-1
		Reporting equipment improvement recommendations (EIR) .....	1-1
		Reference Designations .....	1-4
SECTION	2.	FUNCTIONING OF EQUIPMENT	
	I.	Block Diagram Discussion	
		Overall Function .....	2-1
		Block Diagram .....	2-2
	II.	Circuit Discussion	
		Equipment Interconnection .....	2-3
		Circuit Functioning.....	2-4
	III.	Printed Circuit Board and Integrated Circuits Functioning	
		Converter Test Set and Detecting Set Common Boards .....	2-5
		250/150 Vdc Power Supply, 1A1A3 .....	2-6
		250/150 Vdc Power Supply, 1A1A4 .....	2-7
		Power Control, 1A1A6 .....	2-8
		Cs-vc Simulator, 1A1A7 .....	2-9
		Sync Interface, 1A1A9 .....	2-10
		Hot Target and Slew Voltage Generator, 1A1A10.....	2-11
		Load Board Number One 1A1A11, and Number Two 1A1A12 .....	2-12
		Heatsink Assembly, 1A1A13 .....	2-12
		Heatsink Assembly, 1A1A14.....	2-12
		Filter Assembly, 1A1A5 .....	2-12
		Signal Generator, 2A1A1 .....	2-16
		Sweep and Blanking, 2A2A12 .....	2-16
		Storage Tube Protect, Loads, and Video Amplifier, 2A1A13 .....	2-17
		Heatsink Assembly, 2A1A15 .....	2-18
		Integrated Circuits .....	2-20
CHAPTER	3.	GENERAL SUPPORT MAINTENANCE	
SECTION	I.	General	
		Level of Maintenance .....	3-1
		Maintenance Forms and Records .....	3-1
		Tools and Test Equipment .....	3-3
	II.	Troubleshooting	
		General Troubleshooting Instructions.....	3-2
		Organization of Troubleshooting .....	3-3
		Interunit Troubleshooting .....	3-22
	III.	Removal and Replacement	
		Removal .....	3-7
		Replacement .....	3-8
	IV.	Adjustment and Alignment	
		Adjustment Procedures.....	3-9
		Alignment .....	3-10
	V.	Repairs	
		Parts Replacement Techniques .....	3-11
		Parts Substitution .....	3-12
	VI.	General Support Test Procedures	
		Purpose and Instructions .....	3-13
		Test Equipment Required for Testing .....	3-14
		Test Procedure .....	3-15
APPENDIX		References .....	A-1

**List of Tables**

Table no.	Title	Page
2-1	- 15 Vdc Distribution .....	2-5
2-2	+ 5 Vdc Distribution .....	2-5
2-3	+ 250 Vdc Distribution.....	2-5
2-4	+ 150 Vdc Distribution.....	2-5
2-5	+ 6.3 Vdc Distribution.....	2-5
2-6	+ 6.3 Vdc Return Distribution .....	2-6
2-7	+ 15 Vdc Distribution .....	2-6
2-8	Cross Reference of Converter Test Set Printed Circuit Boards to Detecting Set Printed Circuit Boards .....	2-6
3-1	Test Equipment .....	3-1
3-2	Voltage Measurements .....	3-14
3-3	Resistance Measurements.....	3-15
3-4	Continuity Measurements .....	3-16

**List of Charts**

Chart	Title	Page
3-1	Oscilloscope AN/USM-281A Control Settings.....	3-1
3-2	Troubleshooting Procedure .....	3-3
3-3	General Support Test Procedure.....	3-31

## List of Illustrations

Figure	Title	Page
2-1	Interconnection diagram .....	2-4
2-2	150/250 vdc power supply 1A1A3 and 1A1A4, schematic diagram .....	2-8
2-3	Power control 1A1A6, schematic diagram .....	2-9
2-4	Cs-vc simulator 1A1A7, schematic diagram .....	2-11
2-5	Sync interface 1A1A9, schematic diagram .....	2-13
2-6	Hot target and slew voltage generator 1A1A10, schematic diagram .....	2-14
2-7	Load board number one 1A1A11, schematic diagram .....	2-15
2-8	Load board number two 1A1A12, schematic diagram .....	2-16
2-9	Heatsink assembly 1A1A13, schematic diagram .....	2-17
2-10	Heatsink assembly 1A1A14, schematic diagram .....	2-18
2-11	Filter assembly 1A1A15, schematic diagram .....	2-19
2-12	Sweep and blanking 2A1A12, schematic diagram .....	2-20
2-13	Storage tube protect, loads and video amplifier 2A1A13, schematic diagram.....	2-21
2-14	Heatsink assembly 2A1A15, schematic diagram.....	2-22
2-15	Integrated circuit, type SN5404.....	2-23
3-1	Test setup .....	3-2
3-2(1)	Waveforms (part 1 of 7) .....	3-8
3-2(2)	Waveforms (part 2 of 7) .....	3-9
3-2(3)	Waveforms (part 3 of 7) .....	3-10
3-2(4)	Waveforms (part 4 of 7) .....	3-11
3-2(5)	Waveforms (part 5 of 7) .....	3-12
3-2(6)	Waveforms (part 6 of 7) .....	3-13
3-2(7)	Waveforms (part 7 of 7) .....	3-14
3-3(1)	Parts location, control unit 1A1 (part 1 of 2).....	3-23
3-3(2)	Parts location, control unit 1A1 (part 2 of 2).....	3-24
3-4(1)	Parts location, control unit 2A1 (part 1 of 2) .....	3-25
3-4(2)	Parts location, control unit 2A1 (part 2 of 2) .....	3-26
3-5	Parts location, filter assembly.....	3-27
FO-1	Color code for military standard resistors, inductors, and capacitors.....	FO-1
FO-2	Block diagram, control unit A1.....	FO-2
FO-3	Block diagram, control unit 2A1 .....	FO-3
FO-4(1)	Overall schematic diagram, control unit 1A1 (part 1 of 2) .....	FO-4
FO-4(2)	Overall schematic diagram, control unit 1A1 (part 2 of 2) .....	FO-5
FO-5(1)	Overall schematic diagram, control unit 2A1 (part 1 of 2) .....	FO-6
FO-5(2)	Overall schematic diagram, control unit 2A1 (part 2 of 2) .....	FO-7
FO-6	Signal generator 2A1A1, schematic diagram .....	FO-8
FO-7(1)	Wiring diagram, unit 1 (part 1 of 4) .....	FO-9
FO-7(2)	Wiring diagram, unit 1 (part 2 of 4) .....	FO-10
FO-7(3)	Wiring diagram, unit 1 (part 3 of 4).....	FO-11
FO-7(4)	Wiring diagram, unit 1 (part 4 of 4).....	FO-12
FO-8(1)	Wiring diagram, unit 2 (part 1 of 4).....	FO-13
FO-8(2)	Wiring diagram, unit 2 (part 2 of 4).....	FO-14
FO-8(3)	Wiring diagram, unit 2 (part 3 of 4).....	FO-15
FO-8(4)	Wiring diagram, unit 2 (part 4 of 4).....	FO-16
FO-9	Cable diagram .....	FO-17

## CHAPTER 1

### INTRODUCTION

---

#### 1-1. Scope of Manual

a. This manual contains functioning of equipment and general support maintenance for Test Set, Converter Subassembly-Video Converter AN/AAM-35. General support maintenance includes troubleshooting, removal and replacement, adjustment and alignment, repair and general support testing.

b. Operator and organizational maintenance procedures are contained in Technical Manual (TM) 11-6625-1824-12.

#### 1-2. Consolidated Index of Army Publications and Blank Forms

Refer to the latest issue of DA Pam 310-1 to determine whether there are new editions, changes or additional publications pertaining to the equipment.

#### NOTE

**Applicable forms and records are covered in TM 11-6625-1824-12.**

#### 1-3. Reporting Errors and Recommending Improvements

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms) directly to: Commander, US Army Communications-Electronics Command and Fort Monmouth, ATTN: DRSEL-ME-MP, Fort Monmouth, NJ 07703. In either case, a reply will be furnished directly to you.

#### 1-3.1. Reporting Equipment Improvement Recommendations (EIR)

If your AN/AAM-35 needs improvement, let us know. Send us an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design. Put it on an SF 368 (Quality Deficiency Report). Mail it to Commander, US Army Communications-Electronics Command and Fort Monmouth, ATTN: DRSEL-ME-MP, Fort Monmouth, NJ 07703. We'll send you a reply.

#### 1-4. Reference Designations

Reference designations for major components of Test Set, Converter Subassembly-Video Converter AN/AAM-35 are listed in TM 11-6625-1824-12.