

**TECHNICAL MANUAL**

**ORGANIZATIONAL, DIRECT SUPPORT, AND  
GENERAL SUPPORT MAINTENANCE REPAIR**

**PARTS AND SPECIAL TOOLS LISTS**

**(INCLUDING DEPOT MAINTENANCE REPAIR**

**PARTS AND SPECIAL TOOLS)**

**FOR**

**TEST SET, TRANSPONDER SET**

**AN/APM-305A**

**(NSN 6625-01-052-3881)**

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT  
 MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS  
 (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)  
 FOR

TEST SET, TRANSPONDER SET AN/APM-305A  
 (NSN 6625-01-052-3881)

Current as of 3 January 1979

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 2028-2 located in the back of the manual. Simply tear out the self addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Forms 2028-2 in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, NJ 07703.

In either case a reply will be furnished direct to you.

Table of Contents

		Page	Illus . figure
Section I.	Introduction . . . . .	1	
II.	Repair parts list . . . . .	5	
Group 00	Test Set, Transponder Set AN/APM-305A . . . . .	5	1
01	Test Set, Transponder TS-3395A/APM-305 . . . . .	11	2
	0101 PRF Generator . . . . .	17	3
	0102 Delay Trigger . . . . .	19	4
	0103 Clock and Trigger Logic . . . . .	23	5
	0104 Challenge and Word A/B Counter . . . . .	27	6
	0105 Challenge and Word A/B Encoder . . . . .	29	7
	0106 Variable Pulse Position and Timing Markers . . . . .	31	8
	0107 ISLS Delay and Shapers . . . . .	35	9
	0108 Mode 4 Interface and BIT..... . . . .	37	10
	0109 Sweep Generator and Timing Markers . . . . .	41	11
	0110 Peak Power Video and PRF . . . . .	45	12
	0111 Extender Board Assembly . . . . .	49	13
	0112 RF Generator . . . . .	51	14
	011201 RF Source Assembly . . . . .	53	15
	01120101 Primary Frequency Loop . . . . .	55	16
	01120102 Power Oscillator . . . . .	59	17
	011202 Marker Ramp Generator . . . . .	63	18
	0113 RF BIT/Mixer Assembly.. . . . .	67	19
	0114 Modulator, Dual Signal Generator . . . . .	71	20
	011401 Printed Wiring Board Assembly, Dual Modulator . . . . .	73	21
	0115 Detector Amplifier . . . . .	77	22
	0116 Power Supply Assembly.. . . . .	81	23
	011601 Circuit Card Assembly (PS1A1). . . . .	85	24
	011602 Circuit Card Assembly (PS1A2). . . . .	89	25
	0117 Control Panel Assembly . . . . .	95	26
	0118 Cable Assemblies, RF (152177 -- and 152178 --) . . . . .	101	27
	0119 Instrument Case . . . . .	105	28
Group 02	Cover, Test Set MX944/APM-305A . . . . .	107	29
03	Cable Assembly, Power . . . . .	109	30
04	Cable Assembly, RF . . . . .	111	31
05	Cable Assembly, Video . . . . .	113	32
06	Cable Assembly, RF . . . . .	115	33
Section III.	Special tool list (Not applicable) . . . . .		
IV.	National stock number and part number index . . . . .	116	

# SECTION I

## INTRODUCTION

### 1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational, direct support, and general support maintenance of the AN/APM-305A. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

### 2. General

This Repair Parts and Special Tools List is divided into the following sections:

*a. Section II. Repair Parts List.* A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

*b. Section III. Special Tools List.* Not applicable.

*c. Section IV. National Stock Number and Part Number Index.* A list, in National item identification number (N I IN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

### 3. Explanation of Columns

*a. Illustration.* This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* The number used to identify item called out in the illustration.

*b. Source, Maintenance, and Recoverability (SMR) Codes.*

(1) *Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

<i>Code</i>	<i>Definition</i>
PA-	Item procured and stocked for anticipated or known usage.
PD-	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE-	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
XA-	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XD-	A support item that is not stocked. When required, item will be procured through normal supply channels.

**NOTE**

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

<i>Code</i>	<i>Application/Explanation</i>
O-	Support item is removed, replaced, used at the organizational level.
H -	Support item is removed, replaced, used at the general support level.
D-	Support items that are removed, replaced, used at depot, mobile depot, specialized repair activity only.