

**TECHNICAL MANUAL**

**OPERATOR'S AND ORGANIZATIONAL**

**MAINTENANCE MANUAL**

**TEST SET GROUP, INDICATOR, RADAR**

**OQ-63A/APS-94D**

**(NSN 6625-01-058-7874)**

**This copy is reprint which includes current  
pages from Changes 1 and 2.**

**HEADQUARTERS, DEPARTMENT OF THE ARMY**  
**JANUARY 1979**

TECHNICAL MANUAL  
No. 11-5895-967-12



HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, DC, 30 January 1979

**OPERATOR'S AND ORGANIZATIONAL MAINTENANCE MANUAL**

**TEST SET GROUP, INDICATOR, RADAR OQ-63A/APS-94D  
(NSN 6625-01-058-7874)**

**REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS**

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedure, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in back of this manual direct to: Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, NJ 07703. In either case, a reply will be furnished direct to you.

		Paragraph	Page
CHAPTER 1.	INTRODUCTION		
Section I.	General		
	Scope .....	1-1	1-1
	Index of publications .....	1-2	1-1
	Forms and records .....	1-3	1-1
	Reporting equipment improvement recommendations (EIR) .....	1-4	1-1
	Preparation for storage or shipment .....	1-5	1-1
	Destuction of army electronics materiel .....	1-6	1-1
	Hand receipts .....	1-6.1	1-1
II.	Description and data		
	Purpose and use .....	1-7	1-1
	Equipment data .....	1-8	1-2
	Components and dimensions .....	1-9	1-3
	Common names .....	1-10	1-4
	Description of major components .....	1-11	1-5
	Description of minor components .....	1-12	1-5
CHAPTER 2.	INSTALLATION AND OPERATING INSTRUCTIONS		
Section I.	Service upon receipt of equipment		
	Unpacking .....	2-1	2-1
	Checking unpacked equipment .....	2-2	2-1
II.	Operating Instructions		
	Operator's controls and indicators .....	2-3	2-2
	Preoperating checks .....	2-4	2-9
	Test setups .....	2-5	2-11
	Operating procedures .....	2-6	2-11
CHAPTER 3.	MAINTENANCE INSTRUCTIONS		
Section I.	Operator's maintenance		
	Scope of operator's maintenance .....	3-1	3-1
	Tools, materials and equipment required for operator's maintenance.....	3-2	3-1
	Routine services .....	3-3	3-1
	Preventive maintenance checks and services periods .....	3-4	3-1
	Operator's preventive maintenance checks and services (PMCS).....	3-5	3-1
	Operator's weekly checks .....	3-6	3-4

**\*This manual supersedes TM 11-6625-1833-12, 19 November 1970, including all changes.**

	Paragraph	Page
	Cleaning -----	3-7
	Operator's troubleshooting -----	3-8
	Removal and replacement of panel lights -----	3-9
Section II.	Organizational Maintenance -----	
	Scope of organizational maintenance -----	3-10
	Tools, test equipment, and materials required for organizational maintenance -----	3-11
	Organizational preventive maintenance checks and services -----	3-12
	Touchup painting instructions -----	3-13
	Removal, cleaning and replacement of air intake filter -----	3-14
	Organizational troubleshooting -----	3-15
	Cable continuity check and repair -----	3-16
CHAPTER 4.	SHIPMENT AND LIMITED STORAGE -----	
	Disassembly of equipment -----	4-1
	Repacking for shipment or limited storage -----	4-2
APPENDIX A.	REFERENCES -----	A-1
Section B.	COMPONENTS OF END ITEM LIST -----	B-1
Section I.	Introduction -----	B-1
	Scope -----	B-1
	General -----	B-1
	Explanation of columns -----	B-1
	II. Integral components of end item -----	B-3
	III. Basic issue items -----	B-4
APPENDIX C.	ADDITIONAL AUTHORIZATION LIST (not applicable) -----	
	D. MAINTENANCE ALLOCATION CHART -----	D-1
Section I.	Introduction -----	D-1
	II. Maintenance allocation chart for Test Set Group, Indicator, Radar OQ-63A/APS-94D -----	D-3
	III. Tool and test equipment requirements for Test Set Group, Indicator, Radar OQ-63AIAPS-94D -----	D-9
	IV. Remarks -----	D-10
APPENDIX E.	EXPENDABLE SUPPLIES AND MATERIAL LIST -----	E-1
Section I.	Introduction -----	E-1
	Scope -----	E-1
	Explanation of columns -----	E-1
	II. Expendable supplies and material list -----	E-3

**LIST OF ILLUSTRATIONS**

Figure No.	Title	Page
1-1	Test Set Subassembly MX-8638A/APS-94D -----	1-6
1-2	Test Set Subassembly MX-8639A/APS-94D -----	1-7
1-3	Test Set Subassembly MX-9984-APS-94D -----	1-8
1-4	Contents of Case, Test Set CY-7001/APS-94D -----	1-9
1-5	Test Set Subassembly MX-8639A/APS-94D cables, cable adapter, and high voltage splices -----	1-10
1-6	Typical Test Adapter -----	1-13
1-7	Alignment Fixture, Electron Tube MX-9985/APS-94D -----	1-14
1-8	Microscope, Optical SU54/APS-94D -----	1-15
1-9	CRT alignment mask -----	1-16
1-10	Reference thermocouple assembly -----	1-16
2-1	Typical Packaging of Test Set -----	2-1
2-2	Test Set Subassembly MX-8638A/APS-94D (Lower Control Panel) Controls, Indicators and Connectors -----	2-3
2-3	Test Set Subassembly MX-8638A/APS-94D (Upper Control Panel) Controls, Indicators, and Connectors -----	2-5
2-4	Test Set Subassembly MX-8639A/APS-94D Controls, Indicators, and Connectors -----	2-8
2-5	Preoperating Checks, Bench Setup -----	2-10
2-6	Test Setup for Recorder-Processor-Viewer, Radar Mapping RO-495/U -----	2-12
2-7	Test Setup for Generator, Sweep SG-1127/APS-94E -----	2-13
2-8	Test Setup for Control, Radar Set C-7645/APS-94D -----	2-14
2-9	Test Setup for Rack, Electrical Equipment MT-4015/APS-94D -----	2-15
2-10	Test Setup for Low Voltage Power Supply Module 5A6 -----	2-16
2-11	Test Setup for Cockpit Complex -----	2-17
2-12	Test Setup for High Voltage Power Supply Module 10A1A5 -----	2-18

Figure No.	Title	Page
2-13	Test Setup for Metering Roller Drive Assembly 10A1A1A1 -----	2-19
2-14	Test Setup for Servo Amplifier Module 9A1 -----	2-20
2-15	Test Setup for Low Voltage Regulator Module 5A6A1-----	2-21
2-16	Test Setup for Sweep Generator Module 5A5 -----	2-22
2-17	Test Setup for Dc Amplifier Module 5A1, 5A2, 5A3, or 5A4 -----	2-23
3-1	Air Intake Filter Replacement-----	3-6

**LIST OF TABLES**

Table No.	Title	Page
1-1	Table of Components and Dimensions -----	1-3
1-2	Test Set Group, Indicator, Radar OQ-63A/APS-94D, Common Names -----	1-4
1-3	Radar Surveillance Set AN/APS-94E, Common Names -----	1-4
1-4	Description of Cable Assemblies -----	1-11
2-1	Test Set Subassembly MX-8638A/APS-94D (Lower Control Panel) Controls, Indicators, and Connectors -----	2-2
2-2	Test Set Subassembly MX-8638A/APS-94D (Upper Control Panel) Controls, Indicators, and Connectors -----	2-4
2-3	Test Set Subassembly MX-8639A/APS-94D Controls, Indicators, and Connectors-----	2-7
3-1	Operator/Crew Preventive Maintenance Checks and Services -----	3-2
3-2	Operator's Troubleshooting Chart -----	3-4
3-3	Organizational Troubleshooting Chart-----	3-6
4-1	Materials for Fabrication of Shipping Box for Test Set Subassemblies MX-8638A/APS-94D and MX-8639A/APS-94D-----	4-1
4-2	Materials for Fabrication of Shipping Box for Test Set Subassembly MX-9984/APS-94D	4-1

## CHAPTER 1 INTRODUCTION

---

### Section I. GENERAL

#### 1-1. Scope

a. General. This manual describes Test Set Group, Indicator, Radar OQ-63A/APS-94D and provides instructions for installation, operation, operator's and organizational maintenance, and demolition. Also included are instructions for cleaning and inspection of the equipment and replacement of parts available to the operator and organizational technician.

b. Maintenance Allocation Chart. The maintenance allocation chart (MAC) appears in appendix D.

#### 1-2. Index of Publications

a. DA Pam 310-4. Refer to the latest issue of DA Pam 310-4 to determine whether there are new additions, changes, or additional publications pertaining to the equipment.

b. DA Pam 310-7. Refer to the latest issue of DA Pam 310-7 to determine whether there are Modification Work Orders (MWO's) for the equipment.

#### 1-3. Forms and Records

a. Reports of Maintenance and Unsatisfactory Equipment. Use equipment maintenance forms and records in accordance with instructions in TM 38-750.

b. Report of Packaging and Handling Deficiencies. Fill out and forward DD Form 6 (Packaging Improvement Report) as prescribed in AR 700-58/NAVSUPINST 4030.29/AFR 71-13/MCO P4030.29A, and DLAR 4145.8.

c. Discrepancy in Shipment Report (DISREP) (SF 361). Fill out and forward Discrepancy in

Shipment Report (DISREP) (SF 361) as prescribed in AR 55-38/NAVSUPINST 4610.33B/AFR 75-18/MCO P4610.19C and DLAR 4500.15.

#### 1-4. Reporting Equipment Improvement Recommendations (EIR)

If your Test Set Group, Indicator, Radar OQ-63A/APS-94D needs improvement, let us know. Send us an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design. Tell us why a procedure is hard to perform. Put it on an SF 368 (Quality Deficiency Report). Mail it to Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, NJ 07703. We'll send you a reply.

#### 1-5. Preparation for Storage or Shipment

The equipment shall meet the requirements of the operator's preventive maintenance checks and services (para 3-5) prior to storage. Refer to paragraphs 4-1 and 4-2 for packing and packaging the equipment for storage.

#### 1-6. Destruction of Army Electronics Materiel

Destruction of Army electronics materiel to prevent enemy use shall be in accordance with TM 750-244-2.

##### 1-6.1. Hand Receipts

Use the hand receipts in TM 11-626-1833-12HR for property accountability of Test Set Group, Indicator, Radar OQ-63A/APS-94D.

### Section II. DESCRIPTION AND DATA

#### 1-7. Purpose and Use

a. Test Set Group, Indicator, Radar OQ63A/APS-94D is a portable test set that permits bench testing, aligning, calibrating, and troubleshooting of the units and plug-in modules of the radar cockpit complex of Radar Surveillance Set NA/APS-94E.

b. The OQ-63A/APS-94D consists of two major groups of components: Test Set Subassembly

MX-8638A/APS-94D and Test Set Subassembly MX-8639A/APS-94D. The MX-8638A/APS-94D and MX-8639A/APS-94D function together as a single operating unit through interconnecting cables. The MX-8638A/APS-94D simulates the select signals, signal paths, and loads of Recorder-Processor-Viewer, Radar Mapping RO-496/U and Rack, Electrical Equipment MT40156/APS-94D. The MX-8639A/APS-94D simulates the select sig-