

**TECHNICAL MANUAL**

**ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS**

**FOR**

**INDICATORS, CHANNEL ALIGNMENT  
ID-1189/PR(NSN 5820-00-930-9204)**

**AND**

**ID-1189(XE-2)/PR (NSN 6625-00-181-1884)**

---

**HEADQUARTERS, DEPARTMENT OF THE ARMY**

**JANUARY 1978**

THIS PUBLICATION IS A COURTESY QUICK COPY  
FROM THE UNITED STATES ARMY PUBLICATIONS  
DISTRIBUTION CENTER, ST. LOUIS, MISSOURI,  
TO MEET YOUR NEEDS WHILE WE REPLENISH OUR  
REGULAR STOCK.

**ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND  
 SPECIAL TOOLS LISTS  
 FOR  
 INDICATORS, CHANNEL ALIGNMENT  
 ID-1189/PR (NSN 5820-00-930-9204)  
 AND  
 ID-1189 (XE-2)/PR (NSN 6625-00-181-1884)**

*Current as of 4 October 1977*

**REPORTING OF ERRORS**

You can improve this manual by recommending improvements using DA Form 2028-2 (Test) located in the back of the manual. Simply tear out the self-addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Form 20282 (Test) in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Electronics Command. ATTN: DRSEL-MA-Q Fort Monmouth, NJ 07703.

In either case reply will be furnished direct to you.

**Table of Contents**

			Page	Illus Figure
SECTION	I.	Introduction .....	1	
	II.	Repair parts list.....	5	
GROUP	00	Indicators, Channel Alignment ID-1189/PR and ID-1189 (XE-2)/PR....	5	1
	01	Top plate assembly.....	9	2
		0101 Attenuator (No parts authorized)		
		010101 Attenuator board assembly (No parts authorized)		
		0102 Shield assembly: VFO (No parts authorized)		
		010201 Board Assembly: VFO ( No parts authorized)		
		0103 Function board (No parts authorized)		
	02	Case. CY-6078/PR (No parts authorized)		
	03	Adapter, Receiving Set MX-8512 (XE-1)/PR (No parts authorized)		
		0301 Printed circuit board (No parts authorized)		
SECTION	III.	Special tools list (Not applicable)		
	IV.	National stock number and part number index .....	10	

---

\*This manual supersedes so much of TM 11-6625-937-12, 11 July 1967, including Change 1, 4 August 1969 and Change 2, 31 December 1969, as pertains to repair parts and special tools list.

**SECTION I.  
INTRODUCTION**

**1. Scope**

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational maintenance of the ID-1189/PR, ID-1189(XE-2). It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes

**2. General**

authorized to USE and REPAIR support Items. This Repair Parts and Special Tools List is divided into the following sections:

*a. Section II. Repair Parts List.* A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

*b. Section II. Special Tools List.* Not applicable

*c. Section IV. National Stock Number and Part Number Index.* A list. In National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphanumeric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

**3. Explanation of Columns**

*a. Illustration.* This column is divided as follows:

*(1) Figure number.* Indicates the figure number of the illustration on which the item is shown, of the Uniform SMR Code format as follows:

*(2) Item number.* The number used to identify item called out in the illustration.

*b. Source, maintenance, and Recoverability (SMR) Codes.*

*(1) Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SNIR Code format as follows:

<i>Code</i>	<i>Definition</i>
PA—	Item procured and stocked for anticipated or known usage.
XD—	A support item that is not stocked. When

*Code*

*Definition*

required. item will be procured through normal supply channels.

**NOTE**

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 70042.

*(2) Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

*(a)* The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

<i>Code</i>	<i>Application Explanation</i>
O—	Support item is removed, replaced, used at the organizational level.

*(b)* The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

<i>Code</i>	<i>Application Explanation</i>
Z—	Nonreparable. No repair is authorized.

*(3) Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position

*Recoverability*

*Codes*

*Definition*

Z— Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position :3.

*c. National Stock Number.* Indicates the National stock number assigned to the item and will be used for requisitioning purposes.

*d. Part Number.* Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifi-