TECHNICAL MANUAL

ORGANIZATIONAL, DIRECT SUPPORT, AND
GENERAL SUPPORT
MAINTENANCE REPAIR PARTS AND
SPECIAL TOOLS LIST
(INCLUDING DEPOT MAINTENANCE REPAIR
PARTS AND SPECIAL TOOLS)

FOR

POWER SUPPLIES, DC MODULAR,
STM SERIES
PP-7762/U (NSN 6130-01-005-3869)

AND

PP-7763/U (NSN 6130-01-101-0512) PP-7763/U (NSN 6930-01-054-9200) TECHNICAL MANUAL NO. 11-6625-3000-24P

HEADQUARTERS
DEPARTMENT OF THE ARMY,
WASHINGTON, DC, 16 NOVEMBER 1983

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)

FOR

POWER SUPPLIES, DC MODULAR, STM SERIES PP-7762/U (NSN 6130-01-005-3869)

AND

PP-7763/U (NSN 6130-01-101-0512)

PP-7763/U (NSN 6930-01-054-9200)

Current as of 12 July 1983

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, US Army Communications-Electronics Command and Fort Monmouth, ATTN: DR- SEL-ME-MP, Fort Monmouth, NJ 07703. In either case, a reply will be furnished direct to you.

Table of Contents

		Page	Illus Figure
I.	Introduction	1	
II.	Repair Parts List	5	
00	Power Supply PP-7762/U	5	1
01	Control Printed Circuit Board Assembly (A1001	11	2
02	Regulator Printed Circuit Board Assembly	15	3
03	Base Drive Printed Circuit Board Assembly	16	4
00	Power Supply 7763/U	19	5
		23	6
	Bracket Assembly, Transistor Assembly	27	7
	Printed Circuit Board Assembly, Clipper	29	8
	II. 00 01 02 03	I. Introduction II. Repair Parts List 00 Power Supply PP-7762/U 01 Control Printed Circuit Board Assembly (A1001 02 Regulator Printed Circuit Board Assembly 03 Base Drive Printed Circuit Board Assembly 00 Power Supply 7763/U Chassis Assembly Bracket Assembly, Transistor Assembly Printed Circuit Board Assembly, Clipper	I. Introduction

TM 11-6625-3000-24P

			Page	IIIus Figure
GROUP	01	Control Printed Circuit Board Assembly (A100)	35	9
(02	Regulator Printed Circuit Board Assembly	39	10
	03	Output Printed Circuit Board Assembly (A200)	41	11
		Power Supply PP-7764/U	43	12
		Chassis Assembly PP-7764/U	47	13
		Bracket Assembly, Transistor Mounting	51	14
		Printed Circuit Board Assembly, Clipper	53	15
	01	Control Printed Circuit Board Assembly (A 100)	59	16
		Regulator Printed Circuit Board Assembly	63	17
		Output Printed Circuit Board Assembly (A200)	65	18
SECTION		Special Tools List Not applicable)		
		National Stock Number and Part Number Index	66	

SECTION I

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE). and other special support equipment required for performance of organizational, direct support, and general support maintenance of the PP-7762, /U, PP-7763:'U and PP-7763/U. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

- a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must he removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.
 - b. Section III. Special Tools List. Not applicable.
- c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

- a. *Illustration*. This column is divided as follows:
- (1) Figure number. Indicates the figure number of the illustration on which the item is shown.
- (2) *Item number.* The number used to identify item called out in the illustration.
- b. Source Maintenance, and Recoverability (SMR) codes.
- (1) Source *code*. Source codes indicate the manner of acquiring support items for maintenance, repair. or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SIR Code format as follows:

Code Definition

PA— Item procured and stocked for anticipated or known usage.

Code Definition

- XA— is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
- XD— A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 750-1.

- (2) Maintenance code Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:
- (a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code Application/Explanation

- H— Support item is removed, replaced, used at the general support level.
- (b) The maintenance code entered in the fourth positions indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code Application/Explanation

- H— The lowest maintenance level capable of complete repair of the support item is the general support level.
- Z— Nonreparable. No repair is authorized.
- (3) Recoverability code. Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows: