

This copy is a reprint which includes current pages from Change 1.

---

**TECHNICAL MANUAL  
ORGANIZATIONAL, DIRECT SUPPORT AND  
GENERAL SUPPORT MAINTENANCE  
REPAIR PARTS AND  
SPECIAL TOOLS LIST  
(INCLUDING DEPOT MAINTENANCE REPAIR  
PARTS AND SPECIAL TOOLS)  
FOR  
DIGITAL CARD TESTER  
TEST SET AN/USM-465A  
(NSN 6625-01-126-2473)**

**This publication is required for official use or for administrative or operational purposes only. Distribution is limited to US Government Agencies. Other requests for this document must be referred to Commander, US Army Communications-Electronics Command and Fort Monmouth  
ATTN: AMSEL-MEP, Fort Monmouth, NJ 07703-5007**

---

**H E A D Q U A R T E R S , D E P A R T M E N T O F T H E A R M Y  
1 S E P T E M B E R 1 9 8 6**

**ORGANIZATIONAL, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE  
REPAIR PARTS AND SPECIAL TOOLS LIST  
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)**

**FOR**

**DIGITAL CARD TESTER SET AN/USM-465A  
(NSN 6625-01-126-2473)**

**Basic Manual Current as of 22 April 1986  
Change 1 Current as of 15 February 1989**

**REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS**

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in back of this manual direct to: Commander, US Army Communications-Electronics Command and Fort Monmouth, ATTN: AMSEL-LC-ME-PS, Fort Monmouth, New Jersey 07703-5000. In either case, a reply will be furnished direct to you.

*Table of Contents*

|         |    |   | Page | Illus/<br>Figure |
|---------|----|---|------|------------------|
| Section | I  | Introduction.....   | 1    |                  |
|         | II | Repair Parts List .....   | 1-1  |                  |
| Group   | 00 | Digital Card Tester Test Set                                    |      |                  |
|         |    | AN/USM-465A .....   | 1-1  | 1                |
|         | 01 | Digital Card Tester .....                                       | 2-1  | 2                |
|         |    | 0101 Tester Assembly.....                                       | 3-1  | 3                |
|         |    | 010101 Cage Card Assembly .....                                 | 4-1  | 4                |
|         |    | 01010101 Circuit Card Assembly,<br>Printer Drive .....          | 5-1  | 5                |
|         |    | 01010102 Motherboard Assembly .....                             | 6-1  | 6                |
|         |    | 01010103 Tape Drive Assembly .....                              | 7-1  | 7                |
|         |    | 0101010301 Circuit Card Assembly,<br>Tape Drive Interface ..... | 8-1  | 8                |

\*This manual supersedes TM 11-6625-3038-24P, 20 September 1983.

Table of Contents - Continued

|         |  | Page | Illus/<br>Figure |
|---------|--|------|------------------|
| Group   | 0101010302 Tape Deck.....                              | 9-1  | 9                |
|         | 010102 Circuit Card Assembly,<br>Keyboard.....         | 10-1 | 10               |
|         | 010103 Circuit Card Assembly,<br>Display.....          | 11-1 | 11               |
|         | 010104 Circuit Card Assembly,<br>Driver Sensor.....    | 12-1 | 12               |
|         | 010105 Circuit Card Assembly,<br>Pin Processor.....    | 13-1 | 13               |
|         | 010106 Circuit Card Assembly,<br>Processor.....        | 14-1 | 14               |
|         | 010107 Circuit Card Assembly,<br>Peripheral.....       | 15-1 | 15               |
|         | 010108 Circuit Card Assembly,<br>512K Memory.....      | 16-1 | 16               |
|         | 010109 Circuit Card Assembly,<br>Reference 2703.....   | 17-1 | 17               |
|         | 01010901 Circuit Card Assembly,<br>Reference 2708..... | 18-1 | 18               |
|         | 010110 Power Supply.....                               | 19-1 | 19               |
|         | 0102 Case Assembly.....                                | 20-1 | 20               |
|         | 0103 Fold-Down Adapter.....                            | 21-1 | 21               |
| 02      | Diagnostic Kit.....                                    | 22-1 | 22               |
| Section | III Special Tools List (Not applicable)                |      |                  |
|         | IV Cross-Reference Indexes                             |      |                  |
|         | National Stock Number Index.....                       | I-1  |                  |
|         | Part Number Index.....                                 | I-4  |                  |
|         | Figure and Item Number Index.....                      | I-10 |                  |

**SECTION I**  
**INTRODUCTION**

---

**1. Scope**

This manual lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of organizational direct support, and general support maintenance of the ANIUSM-465A. It authorizes the requisitioning, issue, and disposition of spares, repair parts and special tools as indicated by the source, maintenance and recoverability (SMR) codes.

**2. General**

This Repair Parts and Special Tools List is divided into the following sections:

*a. Section II. Repair Parts List.* A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending numeric sequence, with the parts in each group listed in ascending item number sequence. Figure numbers are listed directly beneath the group header.


*b. Section III. Special Tools List.* Not applicable.

*c. Section IV: National Stock Number and Part Number Index.* A list, in National item identification number (NIIN) sequence, of all National stock numbered items appearing in the listing, followed by a list in alphameric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance .

**3. Explanation of Columns (Section II and III)**

*a. Item No. (Column 1)).* Indicates the number used to identify items called out in the illustration.

*b. SMR Code (Column (2)).* The source, maintenance, and recoverability (SMR) code is a five-position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instruction, as shown in the following breakout:



**NOTE**

**Complete repair: Maintenance capacity, capability, and authority to perform all corrective maintenance tasks of the "Repair" function in a use/user environment in order to restore serviceability to a failed item.**